


# OPERATION & MAINTENANCE MANUAL



DRAWING NO. 20156 REV. N/C

## **MODEL TMS1000D**

**© COPYRIGHT 2018 PNEUMERCATOR CO., INC.**  
**1785 EXPRESSWAY DRIVE NORTH**  
**HAUPPAUGE, NY 11788**

TEL: (631) 293-8450  
FAX: (631) 293-8533  
<http://www.pneumercator.com>



Note: A separate INSTALLATION MANUAL is available, but NOT required for TMS1000D operation.


TABLE OF CONTENTS
-------------------

	Page
Section 1	SYSTEM OVERVIEW
1.1	Front Panel Description ..... 4
1.2	Display..... 5
1.3	Audible Annunciator ..... 5
Section 2	OPERATION
2.1	Power-up Sequence ..... 6
2.2	Overview ..... 7
2.3	View Mode..... 8
2.4	Access Mode ..... 10
2.5	Test Mode ..... 11
Section 3	ACCESS MODE MENUS
3.1	LOG ..... 12
3.1.1	Inventory ..... 13
3.1.2	Delivery..... 14
3.1.3	Sales..... 15
3.1.4	Thefts..... 16
3.1.5	Product Order ..... 17
3.1.6	Alarms ..... 18
3.1.7	Events..... 19
3.2	CONFIGURATION ..... 20
3.2.1	Header..... 21
3.2.2	Tank..... 24
3.2.3	Probe ..... 30
3.2.4	Relay Tank ..... 32
3.2.5	Relay Contact Closure..... 34
3.2.6	Relay Sensor ..... 35
3.2.7	Relay Site ..... 36
3.2.8	Relay Mode ..... 37
3.2.9	Contact Closure Input..... 40
3.2.10	Sensor Input ..... 42
3.2.11	Inventory ..... 44
3.2.12	Theft ..... 46
3.2.13	Modem..... 48
3.2.14	Dialout ..... 49
3.3	CLOCK ..... 52
3.4	INITIALIZE DATA ..... 53
Appendix A	Detailed definitions of TMS Alarm, Events, and Warnings Codes..... 54
Appendix B	Maintenance ..... 58
Appendix C	TMS DIP Switch Settings ..... 60

**SECTION 1 – SYSTEM OVERVIEW**

**1.1 FRONT PANEL DESCRIPTION**


As illustrated in Figure 1-1 below, the TMS1000D front panel consists of an LED data display presented in either English or Metric units, depending on the site’s requirements, with visual alarm and mode annunciators, audible alarm annunciator, and user-friendly pushbutton controls.



**Figure 1-1 – Front Panel Overview**

**1.2 DISPLAY**

The front panel display consists of a nine-digit, seven segment, quasi-alphanumeric super bright LED display, providing on site viewing of current inventory data, alarms, errors, report logs, as well as, set-up and configuration data. Five high intensity point LEDs annunciate alarm conditions visible up to 75 feet away from console. Five additional LED annunciators provide indication of units of measure of the currently selected display data. See Figure 1-2 below.



**Figure 1-2 – Front Panel Display**

**1.3 AUDIBLE ANNUNCIATOR**

A front panel horn is provided to annunciate both user-selectable alarms as well as communications failures. The horn can be silenced manually by pressing the Reset pushbutton, automatically by eliminating the alarm condition, or by programming an audible alarm shutoff. Under alarm conditions, the beep rate of the annunciator varies with the alarm type as follows:

Alarm Group	Alarm Type	Beep Rate
Tank	Critical High, Critical Low	Medium Fast (100ms)
	High High, Low Low	Medium Slow (200ms)
	High, Low	Slow (400ms)
	Bottom Water	Slow (400ms)
Sensor	Leak	Fast (50ms)
	Point Level (High, Low, etc)	Slow (400ms)
	Fault	Slow (400ms)
Contact Closure	All	Slow (400ms)
System	All	Slow (400ms)
		ms = milliseconds

## **SECTION 2 – OPERATION**

### **2.1 POWER-UP SEQUENCE**


Upon application of AC power, the TMS performs a series of tasks prior to normal operation. These include in the following sequence;

1. A self-test to verify integrity of both system program and data memories, system I/O, and data acquisition interface electronics. Display is blank during this process.
2. Retrieval and verification of configuration and set-up data.  
Display shows "**rEAd inG/ConF iG**" (Reading/Configuration).
3. System initialization, including pre-start-up calculations.  
Display shows "**SYStEm/ in it**" (System/Initialization).
4. Firmware version identification. The TMS displays the current firmware versions installed in the system. This information may be requested by Pneumercator's Technical Support department for troubleshooting purposes.
5. Visual display and audible alarm check.  
Display shows "**88888888**" (88888888) with all LEDs on, audible alarm beeps **twice**.
6. Begin normal operation, display any error messages. For a description of system error, warning and info messages, refer to **Appendix A**.

Note: In cases where the TMS power has been turned off for more than one to two minutes, a power-up sequence will generate the following warning message on the display, "**WARn2 I/Pur FR iL**" Warning 21, Power Failure. This message is normal, and is just informing the user that the TMS has detected a power failure. Once acknowledged by the user by pressing the Mode pushbutton, this message will disappear from the display.

**2.2 OVERVIEW**

TMS front panel operation is defined by three user-selectable modes, View, Access, and Test, all selected using the MODE and TEST pushbuttons. See Figure 2-1, System Function Tree below.



TMS1000D System Function Tree

**Figure 2-1 – System Function Tree**

**View:** The View mode is the most frequently used and the default mode of operation for the console. The View mode displays current tank data, which includes product gross, net (temperature compensated) volumes, percent of capacity, 90% ullage, product and water levels, product temperature, and product type. In addition, alarm and error conditions are annunciated in the View mode.

**Access:** The access mode provides access to all of the menus and submenus shown in Figure 2-1. In this mode the user can review report logs; review and edit system configuration data; perform initialization functions; and read or set the system clock.

**Test:** The Test mode allows visual verification of display operation, audible verification of the audible annunciator, and self-verification of critical system hardware.

### 2.3 VIEW MODE

Looking at the names assigned to the console front panel pushbuttons and display field, note that some appear in black lettering, others in orange. Only the **black**-lettered name assignments apply to the **VIEW** mode.

The seven-segment data display is formatted so that the currently selected data item appears on the right-hand side as indicated on the front panel. The LED annunciators on the left-hand side indicate alarm conditions. An alarm indicator is active when the particular LED is on.

**Pushbutton Operation:**


**MODE:** The MODE pushbutton functions both as a Display Mode Select (i.e. STEP) and a Product Name Recall. If the user depresses and holds MODE until an Audible beep is heard, the display will step to the next display item. Display items include, in order of appearance;

Display Item	English		Metric	
	Units	Resolution	Units	Resolution
Gross Volume (uncompensated)	Gallons	x1	Liters	x1
Net Volume (temperature compensated)	Gallons	x1	Liters	x1
Percent Volume	% Gallons	x0.1	% Liters	x0.1
90% Ullage	Gallons	x1	Liters	x1
Product Level	Inches	x0.1	Millimeters	x1
Water Level	Inches	x0.1	Millimeters	x1
Product Temperature	°F	x+/-0.1	°C	x+/-0.1

To recall the name of the product stored, depress and immediately release MODE. The product name will appear for two seconds, and then the display will revert back to displaying the currently selected data item.

**RESET:** The RESET pushbutton is used to provide an acknowledgement of the integrated audible annunciator. The RESET button will have no effect on the Alarm LEDs.

**TEST:** The Test mode allows visual verification of display operation, audible verification of the audible annunciator, and self-verification of critical system hardware.



DRAWING NO. 20159 REV. N/C

**Figure 2-2 – Front Panel Buttons**

**Front Panel Alarm Acknowledgment:**

Alarm, error or warning conditions, which occur during VIEW mode, will activate the front panel visual and audible annunciators. Depending upon user configuration programming, the user can silence the audible annunciator by momentarily pressing **any** front panel pushbutton. The visual annunciator will remain active until the alarm or error condition is eliminated. If subsequent alarm errors, or warnings occur, the audible annunciator will again be activated.



See below: Actual TMS Visual representation of Front Panel displayed items, in order of appearance:

GAL  
 %GAL  
 ULL  
 IN  
 °F

Gross Volume = 10679 Gallons

LTR  
 %LTR  
 ULL  
 MM  
 °C

Net Volume = 10596 Liters

GAL  
 %GAL  
 ULL  
 IN  
 °F

Percent Volume = 79.7% of Capacity

LTR  
 %LTR  
 ULL  
 MM  
 °C

90% Ullage = 1380 Liters  
(90% is default)

GAL  
 %GAL  
 ULL  
 IN  
 °F

Product Level = 106.8 Inches

GAL  
 %GAL  
 ULL  
 IN  
 °F

Product Temperature = 72.1°F

Pressing the MODE button until the TMS BEEPS, will advance through the above list




GAL  
 %GAL  
 ULL  
 IN  
 °F

Product Type = DEF

Press and release MODE to reveal Tank Name

2.4 ACCESS MODE



TMS1000D System Function Tree

Within the **ACCESS** mode there are several levels of menus and sub-menus, as illustrated in Figure 2-1. The main menus include **LOG** reports, **CONFIGuration**, **CLOCK** read/set, and Log/Configuration memory **INITialization**. Note: that the LOG and CONFIG main menus contain numerous sub-menus. These sub-menus will be described in detail later in this section. The main menus are as follows:

- Lo9** The LOG menu is used to review any of the various log reports generated by the TMS. The system does not allow the user to edit any of these reports.
- Conf 9** The CONFIGuration menu is used to review or edit system configuration data.
- C lock** The CLOCK menu is used to edit system date, time, and day of the week.
- in it dRtR** The INITialization menu is used to initialize all or selected log report groups, or configuration memory.

**How to enter the ACCESS mode:**

The **ACCESS** mode is entered by first pressing and holding **TEST**, and then, while still holding **TEST**, simultaneously pressing and holding **MODE**. After approximately two seconds, the **TMS** will enter the **ACCESS** mode. The display will appear as follows:




Note: The **TMS** front panel contains both black text, and orange text. Where present, the **orange** name assignments apply while in the **ACCESS** mode.

**Pushbutton Operation:**

Within the **ACCESS** mode there are two basic types of operations that the user can perform: **REVIEW** and **EDIT**. As seen on the **TMS** front panel, the three right-hand pushbuttons have different functions assigned to them for **REVIEW** and **EDIT** operations.

**REVIEW:** **REVIEW** is the normal mode of operation within the **ACCESS** mode, and is used to examine or review log, configuration, or clock data within the system. **REVIEW MODE** is available in all menus and sub-menus.



DRAWING NO. 20159 REV. N/C

**STEP:** The **STEP** pushbutton functions both as a **STEP-to-the-next-item** and a **Data Name Recall**. If the user depresses and holds **STEP** until an audible beep is heard, the display will step to the next menu data item. To recall the name of the menu data item the user momentarily depresses **STEP**. The menu data item name will appear for two seconds, and then the display will revert back to displaying the currently selected data item.

**GROUP:** The **GROUP** pushbutton selects from a list of numbered menu items. This selection is generic, and refers to the fact that, depending upon which menu the user has entered, **GROUP** will select the next relay, leak sensor, log record, etc.

**EXAMPLE:** If the user enters a relay setup menu, **GROUP** will select the next relay, and the **GROUP ID** display field will indicate the relay number. If the user enters the **INVENTORY LOG** menu, which stores up to 6 records, depressing **GROUP** will step to the next inventory record and the **GROUP ID** display field will represent the inventory record number 1 through 6.

**EDIT:** The EDIT pushbutton is used to edit or change the value of the currently displayed data item. If the displayed item is a menu or sub-menu name, EDIT allows the user to change the menu. If the displayed item is system data, for example, configuration or clock data, the EDIT function is inhibited unless enabled by opening the **EDIT ENABLE** DIP switch 1 located on the main board. An audible beep informs the user when editing is inhibited. Once **EDIT ENABLE** has been opened, editing is enabled for as long as the user remains in the ACCESS mode even if the switch is returned to the closed position. For additional security, if the **TMS** is in the ACCESS mode for more than four minutes and detects no user activity on the front panel pushbuttons, the system will time out and revert back to VIEW mode. Entry back into the ACCESS mode will again require opening **EDIT ENABLE** to re-enable editing.

**EDIT MODE:** EDIT is the mode of operation within the **ACCESS** mode used to modify configuration or clock data within the system. EDIT MODE is available in the CONFIG, CLOCK, and INIT DATA sub-menus.

The names associated with pushbutton functions during edit operations are labeled in **orange** on the front panel as ► (right arrow), ▼ (down arrow), and ▲ (up arrow), as shown in Figure 2-2.

►: For numeric data, advances the blinking cursor to the right to the next digit to be changed. Pressing right arrow while at the right-most digit performs the function of ENTER, and causes the new or changed entry to be stored.

▼: Decrements the content of the blinking portion of the display. For numeric data this button is used to decrement the value of the selected digit. For alphanumeric names, ▼ decrements through a list of name selections.

▲: Increments the content of the blinking portion of the display. For numeric data this button is used to increment the value of the selected digit. For alphanumeric names, ▲ increments through a list of name selections.

## 2.5 TEST MODE

The TEST mode is initiated by depressing the TEST pushbutton. This action activates all of the front panel display LED segments and LED annunciators for visual verification, and will produce a double beep from the audible annunciator for audible verification.

**SECTION 3 – ACCESS MODE MENUS**

**3.1 LOG**

**ACCESS**

<b>LoG</b>	System reports
<b>CoNf iG</b>	System configuration
<b>C loCk</b>	Set system clock
<b>in it iALtA</b>	Resets select data to initialized values
<b>rEturN</b>	Exits access menu

The LOG menus listed below are a grouping of historical or on-demand records.

			<b>Max records</b>
<b>inUentory</b>	Inventory	- Scheduled inventory snapshots	6
<b>dEL iUerY</b>	Deliveries	- Delivery (Product added) transactions	4
<b>SALES</b>	Sales	- Bulk sales (Product removed) transactions	4
<b>tHEFTS</b>	Thefts	- Theft incidents	2
<b>OrdErS</b>	Product Order	- On-demand product reorder report	1
<b>ALARMS</b>	Alarms	- Probe/sensor alarms	12
<b>EvEntS</b>	Errors	- System errors/events	4

**LoG** System Logs/Reports: The LOG menu contains various Logs/Reports that are primarily a grouping of historical recorded events that have been captured and stored in the TMS memory. Once the Log capacity has been reached, the oldest record will be discarded to allow the new entry to be stored. Each Log may be viewed or printed from within each respective submenu. The records may also be retrieved with a Windows-based computer equipped with TMS Communicator software. Logs may NOT be altered by any user or supervisor to maintain the integrity and accuracy of the system Logs. A brief description of each submenu is provided at the bottom of this page. See the following Sections for complete details for each Log submenu. A list of definitions used throughout the LOG submenus are provided below:

**Gross Volume:** The volume of liquid within the storage tank measured in Gallons [Liters].

**Net Volume:** Temperature-Compensated Volume. The Gross Volume is adjusted to the Volume that would be occupied at 60 °F [15.6 °C]. This is used for Inventory reconciliation due to the fact that liquids expand and contract with temperature. The Product Type defined in the Tank submenu of the Configuration menu is used to determine the rate of expansion for a given liquid.

**Height:** Liquid level measured in Inches [Millimeters].

**Inventory:** A scheduled Shift Inventory report as configured in the Inventory submenu of the Configuration menu.

**Delivery:** Addition of Product to the storage tank.

**Sales:** Withdrawal of Product from the storage tank recorded only if the Bulk Sales feature is enabled in the Configuration menu, Header submenu. If Theft is enabled for the specified Tank Channel, the transaction would only be considered a Bulk Sale if the withdrawal occurs during normal business hours as defined in the Configuration menu, Thefts submenu.

**Thefts:** Withdrawal of Product from the tank outside of normal business hours. Thefts are only recorded if Theft monitoring is enabled for the specified Tank Channel as defined in the Tanks submenu in the Configuration menu.

**Orders:** The Product Reorder Log is the only Log that is NOT historical but is an on-demand report that provides an estimate of usable Product remaining based on the amount of Product used since the time of the last Delivery.

**Alarms:** System Alarms including High, Low and Leak conditions.

**Events:** System Errors and Warnings that may represent a critical problem with the TMS.

**3.1.1 INVENTORY LOG**

LOG

			<b>Max</b>
<i>Inventory</i>	<b>Inventory</b>	Scheduled inventory snapshots	6
<i>DELIVERY</i>	Deliveries	Product delivered to storage tank	4
<i>SALES</i>	Bulk Sales	Product sold from storage tank	4
<i>THEFTS</i>	Thefts	Unauthorized withdrawal from tank	2
<i>OrderS</i>	Product Reordering Report	Product reordering report	1
<i>ALARMS</i>	Alarms	Alarms	12
<i>Events</i>	Events	Events/Errors	4
<i>Return</i>	Return	Exits LOG menu	

*Inventory* Inventory A scheduled Inventory data capture typically used as a Shift Report.

**Record Storage Capacity:** 6

**TMS Configuration Prerequisites:**

Configuration menu, Inventory submenu: Defines Times and Days of Week.

**Group ID:** Record Number.

**Record Identification Data:**

*nn-dd* Date (Month-Day): Date the scheduled Inventory Snapshot was recorded.  
 Note: an empty record will show 00-00.

*HH' mm* Time (Hour' Minute): Time the scheduled Inventory Snapshot was recorded.  
 Note: time stored in 24 hr. format

Examples: 12'00 = 12 Noon            23'59 = 11:59 PM            00'00 = Midnight

*TANK NAME* Tank Name: As Assigned in the Configuration menu, Tank submenu.

*Prod TYPE* Product Type: As Assigned in the Configuration menu, Tank submenu.

*TANK ID* Tank ID Number: As Assigned in the Configuration menu, Tank submenu.

**Captured Data:**

*Prod Ht* Product Height: Total Liquid Level.  
 Note: MP452 reports Oil Level.

*Gr Vol* Gross Volume: Total Liquid Volume.  
 Note: MP452 reports Oil Volume.

*Net Vol* Net Volume: Total Net (Temperature-Compensated) Liquid Volume.  
 Note: MP452 reports Net Oil Volume.

*P Vol* Percent Volume: Gross Volume/Tank Capacity displayed as a percentage.

*ULLAGE* Ullage: Gross Volume required to fill tank to defined Ullage Threshold. See Configuration menu, Header submenu, Ullage Limit

*h2o Ht* Bottom Water Height: Bottom Water Level.

*TEMP* Temperature: Average Liquid Temperature.

**Exit Inventory submenu:**

*Return* Return: Press EDIT (TEST) to exit Inventory submenu.

Note: Press STEP (MODE) to return to top of Inventory submenu showing *nn-dd* (Month-Day)

### 3.1.2 DELIVERY LOG

#### Log

<b>Inventory</b>	Inventory
<b>DELIVERY</b>	<b>Deliveries</b>
<b>SALES</b>	Bulk Sales
<b>THEFTS</b>	Thefts
<b>OrderS</b>	Product Reordering Report
<b>ALARMS</b>	Alarms
<b>Events</b>	Events
<b>Return</b>	Return

**DELIVERY** Deliveries: A Transaction Log representing the addition or delivery of the primary liquid or Product to the tank. All transactions depend on the TMS Clock functionality to be recognized.

**Record Storage Capacity:** 4

#### TMS Configuration Prerequisites:

Configuration menu, Probe submenu, Motion Height Band: Defines Transaction recognition  
Configuration menu, Probe submenu, Minimum Logged Volume: Defines Transaction Logging

**Group ID:** Record Number.

#### Record Identification Data:

<b>nn-dd</b>	<u>Date (Month-Day)</u> : Date the Delivery was recorded. Note: an empty record will show 00-00.
<b>HH' nn</b>	<u>Time (Hour' Minute)</u> : Time the Delivery was recorded. Note: time stored in 24 hr. format Examples: 12'00 = 12 Noon      23'59 = 11:59 PM      00'00 = Midnight
<b>TANK NAME</b>	<u>Tank Name</u> : As Assigned in the Configuration menu, Tank submenu.
<b>Prod TYPE</b>	<u>Product Type</u> : As Assigned in the Configuration menu, Tank submenu.
<b>TANK ID</b>	<u>Tank ID Number</u> : As Assigned in the Configuration menu, Tank submenu.

#### Captured Data:

<b>bEG in Ht</b>	<u>Beginning Height</u> : Total Liquid Level at the Beginning of the Delivery.
<b>End Ht</b>	<u>Ending Height</u> : Total Liquid Level at the End of the Delivery.
<b>bEG tEnP</b>	<u>Beginning Temperature</u> : Average Product Temperature at the Beginning of the Delivery.
<b>End tEnP</b>	<u>Ending Temperature</u> : Average Product Temperature at the End of the Delivery.
<b>Gr End</b>	<u>Gross Ending Volume</u> : Total Gross Volume at the End of the Delivery.
<b>Gr bEG in</b>	<u>Gross Beginning Volume</u> : Total Gross Volume at the Beginning of the Delivery.
<b>Gr dIFF</b>	<u>Gross Difference</u> : Total Gross Volume Delivered to tank. Calculated as: (Gross Ending Volume) – (Gross Beginning Volume).
<b>NEt End</b>	<u>Net End Volume</u> : Total Net Volume at the End of the Delivery.
<b>NEt bEG in</b>	<u>Net Begin Volume</u> : Total Net Volume at the Beginning of the Delivery.
<b>NEt dIFF</b>	<u>Net Difference</u> : Total Net Volume Delivered to tank. Calculated as: (Net Ending Volume) – (Net Beginning Volume).

#### Exit Delivery submenu:

**Return** Return: Press EDIT (TEST) to exit Delivery submenu.

Note: Press STEP (MODE) to return to top of Delivery submenu showing **nn-dd** (Month-Day)

**3.1.3 SALES LOG**

**Log**

<b>Inventory</b>	Inventory
<b>DELIVERIES</b>	Deliveries
<b>SALES</b>	<b>Bulk Sales</b>
<b>THEFTS</b>	Thefts
<b>OrderS</b>	Product Reordering Report
<b>ALARMS</b>	Alarms
<b>Events</b>	Events
<b>Return</b>	Return

**SALES**     Bulk Sales: An optional transaction log that represents the withdrawal or sale of the primary liquid or Product from the tank. If Theft monitoring is enabled, a Sale can only occur during defined hours of operation. See Thefts Log on following page for Theft-specific Configuration settings that define a loss of Product as either a Theft or Bulk Sale. All transactions depend on the TMS Clock functionality to be recognized.

**Record Storage Capacity:** 4

**TMS Configuration Prerequisites:**

- Configuration menu, Header submenu, Sales Enable: Enables Bulk Sales tracking
- Configuration menu, Probe submenu, Motion Height Band: Defines Transaction recognition
- Configuration menu, Probe submenu, Minimum Logged Volume: Defines Transaction Logging

**Group ID:** Record Number.

**Record Identification Data:**

<b>nn-dd</b>	<u>Date (Month-Day)</u> : Date the Bulk Sale was recorded. Note: an empty record will show 00-00.
<b>HH' nn</b>	<u>Time (Hour' Minute)</u> : Time the Bulk Sale was recorded. Note: time stored in 24 hr. format Examples: 12'00 = 12 Noon     23'59 = 11:59 PM     00'00 = Midnight
<b>TANK NAME</b>	<u>Tank Name</u> : As Assigned in the Configuration menu, Tank submenu.
<b>Prod TYPE</b>	<u>Product Type</u> : As Assigned in the Configuration menu, Tank submenu.
<b>TANK ID</b>	<u>Tank ID Number</u> : As Assigned in the Configuration menu, Tank submenu.

**Captured Data:**

<b>bEG in Ht</b>	<u>Beginning Height</u> : Total Liquid Level at the Beginning of the Bulk Sale.
<b>End Ht</b>	<u>Ending Height</u> : Total Liquid Level at the End of the Bulk Sale.
<b>bEG tEnP</b>	<u>Beginning Temperature</u> : Average Product Temperature at the Beginning of the Bulk Sale.
<b>End tEnP</b>	<u>Ending Temperature</u> : Average Product Temperature at the End of the Bulk Sale.
<b>Gr bEG in</b>	<u>Gross Beginning Volume</u> : Total Gross Volume at the Beginning of the Bulk Sale.
<b>Gr End</b>	<u>Gross Ending Volume</u> : Total Gross Volume at the End of the Bulk Sale.
<b>Gr dIFF</b>	<u>Gross Difference</u> : Total Gross Volume Sold from tank. Calculated as: (Gross Beginning Volume) – (Gross Ending Volume).
<b>NEt bEG in</b>	<u>Net Beginning Volume</u> : Total Net Volume at the Beginning of the Bulk Sale.
<b>NEt End</b>	<u>Net Ending Volume</u> : Total Net Volume at the End of the Bulk Sale.
<b>NEt dIFF</b>	<u>Net Difference</u> : Total Net Volume Sold from tank. Calculated as: (Net Beginning Volume) – (Net Ending Volume).

**Exit Sales submenu:**

**Return**     Return: Press EDIT (TEST) to exit Sales submenu.  
Note: Press STEP (MODE) to return to top of Sales submenu showing **nn-dd** (Month-Day)



### 3.1.4 THEFTS LOG

#### Log

<i>InventorY</i>	Inventory
<i>dELiverY</i>	Deliveries
<i>SALES</i>	Bulk Sales
<i>tHEFTS</i>	<b>Thefts</b>
<i>OrdErS</i>	Product Reordering Report
<i>ALARMS</i>	Alarms
<i>EventS</i>	Events
<i>rEturN</i>	Return

**tHEFTS** Thefts: An optional transaction log that represents the withdrawal or theft of the primary liquid from the tank during hours when the facility is not in operation. Theft monitoring may be enabled for individual tanks in the Tank submenu of the Configuration menu. The hours of operation are defined in the Theft submenu of the Configuration menu. All transactions depend on the TMS Clock functionality to be recognized.

**Record Storage Capacity:** 2

#### TMS Configuration Prerequisites:

- Configuration menu, Tank submenu, Theft Enable: Enables Theft monitoring.
- Configuration menu, Theft submenu: Defines Hours of Operation for facility
- Configuration menu, Probe submenu, Motion Height Band: Defines Transaction recognition
- Configuration menu, Probe submenu, Minimum Logged Volume: Defines Transaction Logging

**Group ID:** Record Number.

#### Record Identification Data:

<i>nn-dd</i>	<u>Date (Month-Day)</u> : Date the scheduled Inventory Snapshot was recorded. Note: an empty record will show 00-00.
<i>HH' nn</i>	<u>Time (Hour' Minute)</u> : Time the scheduled Inventory Snapshot was recorded. Note: time stored in 24 hr. format Examples: 12'00 = 12 Noon      23'59 = 11:59 PM      00'00 = Midnight
<i>tRnk nRnE</i>	<u>Tank Name</u> : As Assigned in the Configuration menu, Tank submenu.
<i>Prod tYPE</i>	<u>Product Type</u> : As Assigned in the Configuration menu, Tank submenu.
<i>tRnk id</i>	<u>Tank ID Number</u> : As Assigned in the Configuration menu, Tank submenu.

#### Captured Data:

<i>bEG in Ht</i>	<u>Beginning Height</u> : Total Liquid Level at the Beginning of the Theft.
<i>End Ht</i>	<u>Ending Height</u> : Total Liquid Level at the End of the Theft.
<i>bEG tEnP</i>	<u>Beginning Temperature</u> : Average Product Temperature at the Beginning of the Theft.
<i>End tEnP</i>	<u>Ending Temperature</u> : Average Product Temperature at the End of the Theft.
<i>Gr bEG in</i>	<u>Gross Beginning Volume</u> : Total Gross Volume at the Beginning of the Theft.
<i>Gr End</i>	<u>Gross Ending Volume</u> : Total Gross Volume at the End of the Theft.
<i>Gr d iFF</i>	<u>Gross Difference</u> : Total Gross Volume Stolen from tank. Calculated as: (Gross Beginning Volume) – (Gross Ending Volume).
<i>NEt bEG in</i>	<u>Net Beginning Volume</u> : Total Net Volume at the Beginning of the Theft.
<i>NEt End</i>	<u>Net Ending Volume</u> : Total Net Volume at the End of the Theft.
<i>NEt d iFF</i>	<u>Net Difference</u> : Total Net Volume Stolen from tank. Calculated as: (Net Beginning Volume) – (Net Ending Volume).

#### Exit Thefts submenu:

<i>rEturN</i>	<u>Return</u> : Press EDIT (TEST) to exit Thefts submenu. Note: Press STEP (MODE) to return to top of Thefts submenu showing <i>nn-dd</i> (Month-Day)
---------------	--

**3.1.5 PRODUCT ORDER LOG**

**Log**

<b>Inventory</b>	Inventory
<b>Deliveries</b>	Deliveries
<b>SALES</b>	Bulk Sales
<b>THEFTS</b>	Thefts
<b>OrderS</b>	<b>Product Reordering Report</b>
<b>ALARMS</b>	Alarms
<b>Events</b>	Events
<b>Return</b>	Return

**OrderS** Product Reordering Report: An on-demand report for each tank is automatically created upon accessing this menu. This report is used to determine the number of days remaining of usable product in the tank based on the information logged for the last Delivery. These reports are not stored in the TMS historically. See Delivery Log for details regarding the Logging of Deliveries.

**Record Storage Capacity:** N/A

**TMS Configuration Prerequisites:**

Configuration menu, Tank submenu, Unusable Product: Defines a quantity of Product as unusable.

**Group ID:** Tank Channel.

**Record Identification Data:**

- nn-dd** Date (Month-Day): Date the Product Reordering Report was generated.  
Note: an empty record will show 00-00.
- HH' nn** Time (Hour' Minute): Time the Product Reordering Report was generated.  
Note: time stored in 24 hr. format  
Examples: 12'00 = 12 Noon      23'59 = 11:59 PM      00'00 = Midnight
- TANK NAME** Tank Name: As Assigned in the Configuration menu, Tank submenu.
- Prod TYPE** Product Type: As Assigned in the Configuration menu, Tank submenu.
- TANK ID** Tank ID Number: As Assigned in the Configuration menu, Tank submenu.

**Captured Data:**

- dEL dATE** Delivery Date: Date of Last Delivery recorded in the Delivery Log.
- dEL AMt** Delivery Amount: Gross Difference (Gross Volume delivered) recorded in the Delivery Log.
- Gr bEG in** Gross Beginning Volume: Gross Beginning recorded in the Delivery Log.
- Gr End** Gross Ending Volume: Gross Ending recorded in the Delivery Log.
- tOTAL USE** Total Usage: Gross product used since last delivery calculated as:  
(Gross Ending Volume) – (Current Gross Volume)
- dAYS** Days: Number of Days since the last Logged Delivery.
- dA ILY USE** Daily Use: Average daily usage in Gross Volume calculated as:  
(Total Usage) ÷ (Days)
- UsABLE** Usable: Current Usable Gross Volume calculated as:  
(Current Gross Volume) – (Unusable Volume)
- dAYS LEFT** Days Left: Estimated number of days of Usable Gross Volume calculated as:  
(Usable) ÷ (Daily Use)
- ULLAGE** Ullage: Gross Volume required to fill tank to defined Ullage Threshold. See Configuration menu, Header submenu, Ullage Limit.

**Exit Orders submenu:**

- rEtURN** Return: Press EDIT (TEST) to exit Orders submenu.  
Note: Press STEP (MODE) to return to top of Orders submenu showing **nn-dd** (Month-Day)

### 3.1.6 ALARMS LOG

#### Log

<i>InventorY</i>	Inventory
<i>dELiverY</i>	Deliveries
<i>SALES</i>	Bulk Sales
<i>tHEFTS</i>	Thefts
<i>OrderS</i>	Product Reordering Report
<i>ALARMS</i>	<b>Alarms</b>
<i>EventS</i>	Events
<i>rEturN</i>	Return

**ALARMS** Alarms: Records all alarm conditions detected by the TMS. Alarm conditions typically include High or Low liquid or detected Leaks. See list below for a basic list of Alarms or Appendix A for a detailed list.

**Record Storage Capacity:** 12

#### TMS Configuration Prerequisites:

Configuration menu, Tank submenu: Configure Product and Temperature SetPoints.

Configuration menu, CC Input submenu: Configure CC Input as an Alarm.

Configuration menu, Sensor Input submenu: Configure Leak/Point Level Sensor as an Alarm.

**Group ID:** Record Number.

#### Record Identification Data:

*nn-dd* Date (Month-Day): Date the Alarm occurred.

Note: an empty record will show 00-00.

*HH' nn* Time (Hour' Minute): Time the Alarm occurred.

Note: time stored in 24 hr. format

Examples 12'00 = 12 Noon                      23'59 = 11:59 PM                      00'00 = Midnight

#### Captured Data:

*ALARn* Alarm: The Name of the Alarm that occurred. i.e. Sump or High

*Group nnn* Group Number: Group number name changes to reflect hardware in alarm.

*tAnT id* Tank ID: Tank ID configured in TMS.

*inPut id* Input ID: Hardware Input Number for CC or Sensor Input

*ALARn id* Alarm ID: The Category of Alarm that occurred. i.e. Sensor or High

*dEtA iL* Detail: Additional Details that further clarify the combined meaning of Alarm and Alarm ID. i.e. Open or Level

#### Exit Alarms submenu:

*rEturN* Return: Press EDIT (TEST) to exit Alarms submenu.

Note: Press STEP (MODE) to return to top of Alarms submenu showing *nn-dd* (Month-Day)

#### ALARM CONDITIONS INCLUDE:

Product SetPoints (High High, High, Low)

Temperature (High High, High, Low, Low Low)

CC (Non-Hazardous Contact Closure Input)

Sensor

\*For detailed definitions of TMS Alarms, see Appendix A.

**3.1.7 EVENTS LOG**

**Log**

<i>Inventory</i>	Inventory
<i>Deliveries</i>	Deliveries
<i>SALES</i>	Bulk Sales
<i>THEFTS</i>	Thefts
<i>OrderS</i>	Product Reordering Report
<i>ALARMS</i>	Alarms
<i>Events</i>	<b>Events</b>
<i>Return</i>	Return

**Events**     Events: Contains System Errors that represent a possible hardware problem with the system including probes, sensors, and field cabling. Select Non-Alarm Warnings are also recorded in this Log. See list on following page for a basic list of Events or Appendix A for a detailed list.

**Record Storage Capacity:** 4

**TMS Configuration Prerequisites:** N/A

**Group ID:** Record Number.

**Record Identification Data:**

- nn-dd*     Date (Month-Day): Date the Error/Warning occurred.  
Note: an empty record will show 00-00.
- HH' mm*     Time (Hour' Minute): Time the Error/Warning occurred.  
Note: time stored in 24 hr. format  
Examples: 12'00 = 12 Noon                    23'59 = 11:59 PM                    00'00 = Midnight

**Captured Data:**

- Error Num*     Error Number: A 2-digit numeric Error Number.
- Warn Num*     Warning Number: A 2-digit numeric Warning Number.
- Tank id*         Tank ID: As Assigned in the Configuration menu, Tank submenu.
- Input id*       Input ID: As Assigned in the Configuration menu, CC Input or Sensor Input submenu
- Event id*       Event ID: Category of the Event including Probe, Sensor, or Power.
- Detail*         Detail: Provides additional details for the reported Error or Warning

**Exit Events submenu:**

- Return*         Return: Press EDIT (TEST) to exit Events submenu.  
Note: Press STEP (MODE) to return to top of Events submenu showing *nn-dd* (Month-Day)

**Event log reports may contain any combination of the following data:****EVENT CONDITIONS****Errors: Codes:****System**

Serial Prom (CM1) 05

**Probe**

Probe Level 10

Probe Timeout 11

Probe Temperature 13

**Fault detecting sensors**

Sensor Short Circuit 20

Sensor Open Circuit 21

Sensor Wiring Fault 22

**Warnings: Codes:**

Modem Initialization 01

Modem Command 02

Modem Timeout 03

Modem Carrier 04

Modem Communication 05

Modem No dial tone 06

Tank Configuration Checksum 07

Probe Configuration Checksum 08

Header Configuration Checksum 09

Relay Tank Configuration Checksum 10

Relay CC Configuration Checksum 11

Relay Sensor Configuration Checksum 12

Relay Status Configuration Checksum 14

CC Configuration Checksum 15

Sensor Configuration Checksum 16

Inventory Configuration Checksum 17

Theft Configuration Checksum 18

Modem Configuration Checksum 19

Dial out Configuration Checksum 20

Power Failure 21

Front End Communication 28

**Information Messages: Codes:**

Change of SP Units 01

Low Product, Ungaugeable Level 02

**\*For detailed definitions of TMS Events, Warnings, and Information Messages, see Appendix A.**

### 3.2 CONFIGURATION

```

ACCESS      Lo9
            Conf 9
            [ locT
            in it dRtR
            rEturn
    
```

In view mode depressing TEST button first, then MODE and holding both buttons momentarily will increment the TMS into the ACCESS MODE displaying the main menu beginning as follows with LOG. Pressing the EDIT (TEST) button again would cause LOG to blink. Once LOG is blinking, press the ▲ (TEST) button to go to the CONFIG menu. Once CONFIG is blinking, pressing the ► (MODE) button will enter the CONFIG menu revealing the HEADER submenu.

**The CONFIG menu is used to review or edit system configuration data.**

**Note:** Three types of entries require the user to input programming data when configuring the TMS menus. It is mentioned here, to help the user interpret data displayed in the CONFIG menus. This information below will be explained again in the CLOCK section of the manual.

**Entry Type:** Either a numeric value or a list of choices designated by the system.

**Range Limits:** Selects and enters a numeric value within a fixed boundary, set by the system.

**Default/Initialized value:** If not user programmed, this entry, value or term, will be set by the system.

To select and step through other records while in the CONFIG menu, pressing the ▲ (TEST) button at the flashing term such as HEADER will increment the system to the next menu. i.e. TANK, then PROBE, etc. The ▼ (RESET) button at the flashing term such as HEADER will decrement the system to the next menu. i.e. RETURN, then DIAL OUT, etc.

The user may increment through the following submenus in CONFIG to review data in the following categories.

```

Conf 9
    HEAdEr      Header – General System Settings
    tAnk        Tank – Tank Channel specific including geometry and SetPoints
    ProbE       Probe – Level Gauging Probe settings
    rELY tAnk   Relay Tank – Relay Assignments to Tank Channel Specific conditions
    rELY cc     Relay CC – Relay Assignments to individual Non-Hazardous CC Inputs
    rELY SEnS   Relay Sensor – Relay Assignments to individual Leak/Point Level Sensor Inputs
    rELY S itE  Relay Site – Relay Assignments to Site-Specific conditions
    rELY ModE   Relay Mode – Relay-specific behavior settings
    cc inPut    Non-Hazardous Contact Closure (CC) Inputs
    SEnSr inP   Leak/Point Level Sensor Inputs
    InuEntorY   Shift Inventory Report Schedule
    tHEFT       Theft – Detection (Hours of operation)
    ModEn       Modem/Serial C Communications
    d iAL out   Auto-Dial out - Setup for selected Alarms or Tank information
    
```

3.2.1 HEADER

*CONF*

<b>HEAdEr</b>	<b>Header - Global System Settings</b>
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY StE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEr</b>	Modem Communications - Setup
<b>dIAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**HEAdEr**      Header: A collection of General Use and Global Settings for the TMS. It is recommended that these settings are configured prior to configuring other TMS features to ensure the TMS is configured properly and completely.

**Acc Code**      Access Code: A six-digit numeric value used in conjunction with the Communications Security feature to restrict Serial, Network, and Modem communication to the TMS. See Appendix C for configuring TMS DIP switches to enable security feature.  
 Entry Type: 6-digit numeric  
 Range Limits: 000000-999999  
 Default/Initialized value **000000**

**SECur itY**      Security: specifies the communications interfaces where the security feature is enforced. See Appendix C for configuring TMS DIP switches to enable security feature.  
 Entry Type: select list  
 Range Limits: **Serial**: Affects all serial and network interfaces  
                   **Modem**: Affects all modem interfaces  
                   **Both**: Affects all communications interfaces including serial, network, and modem.  
 Default/Initialized value **SEr ,AL**

**Un it id**      Unit ID: Identifies TMS with Site ID when Dialing Out to computer with Autopolling application  
 Entry Type: 2-digit numeric  
 Range Limits: 00-99  
 Default/Initialized value: **00**

**Site id**      Site ID: Identifies TMS with Unit ID when Dialing Out to computer with Autopolling application  
 Entry Type: 3-digit numeric  
 Range Limits: 00000-99999  
 Default/Initialized value: **00000**

**dSP ModE**      Default Display Mode: The TMS will return to the Default Display Mode when no buttons are pressed for approximately four minutes.  
 Entry Type: select list  
 Range Limits: **Gr Vol**: Gross Volume in Gallons/Liters  
                   **Level**: Level in Inches/Millimeters  
                   **PctVol**: Product Gross Volume as a percentage of Total Tank Capacity  
                   **NetVol**: Net (Temperature-Compensated) Volume in Gallons/Liters  
 Default/Initialized value: **Gr Vol**

- bAud rAtE**      Baud Rate: This entry allows the user to select the baud rate for the RS-232 serial communications port in the TMS.  
Entry Type: select list  
Range Limits: 1.2K, 2.4K, 4.8K, 9.6K, 38.4K (K = 1,000. i.e 9.6K =9600)  
Default/Initialized value: **960**
- SEr iALFnt**      Serial Format: This entry allows the user to select the serial format for the RS-232 serial communications port in the TMS.  
Entry Type: select list  
Range Limits: **n,8,1**: No Parity, 8 Data Bits, 1 Stop Bit  
**e,7,1**: Even Parity, 7 Data Bits, 1 Stop Bit  
**o,7,1**: Odd Parity, 7 Data Bits, 1 Stop Bit  
Default/Initialized value: **n-8-1**
- SP1 LEd**  
**SP2 LEd**  
**SP3 LEd**      Product SetPoint LED assignment: Selects which of the six Product SetPoints are mapped to which of the three SP LEDs on the TMS Display. A Product SetPoint is considered to be an Alarm condition when it is associated with an LED. The remaining three Product SetPoints may be used to control Relay Outputs and are represented across all communications interfaces.  
Entry Type: select list  
Range Limits: Critical High, High High, High, Low, Low Low, Critical Low  
Default/Initialized value: SP1 LED: **H ,H ,9h**: High High  
SP2 LED: **H ,9h**: High  
SP3 LED: **Lo**: Low  
**Note**: The default LED assignments are recommended for the TMS1000D due to the matching labelling of the Product SetPoint LEDs.
- SALE En**      Bulk Sales Enable: Enables tracking of Product Sales from the tanks being monitored. A sale is defined as a loss of Product during normal hours of operation. Sales are logged in the Sales Log provided they meet the Minimum Log Volume requirements defined in the Configuration/Probe submenu  
Entry Type: select list  
Range Limits: No, Yes  
Default/Initialized value: **no**
- Horn dELAY**      Horn Autosilence Delay: The integrated horn can be automatically acknowledged after a time delay ranging from 1-9 minutes. This feature is disabled by selecting NONE.  
Entry Type: select list  
Range Limits: None, 1-9  
Default/Initialized value: **none**
- ULL L im it**      Percent Ullage Limit: The maximum fill point defined as a percentage of total tank capacity. The Ullage displayed on the real-time display and contained in system logs will be calculated based on this threshold and is displayed using volume units of gallons/liters  
Entry Type: select list  
Range Limits: 90, 95, 100, 85  
Default/Initialized value: **90**
- dStE EnAbL**      Daylight Savings Time Enable: The TMS can automatically adjust its internal clock based on the 2007 U.S. Daylight Savings Time rules.  
Entry Type: select list  
Range Limits: No, Yes  
Default/Initialized value: **no**
- rEturn**      Return: Press EDIT (TEST) to exit Header submenu.  
Note: Press STEP (MODE) to return to top of Header submenu showing **Acc Code** (Access Code)



3.2.2 TANK

CONF 19

HEAdEr	Header - Global System Settings
tAnk	<b>Tank - Programming setup</b>
PrObE	Probe - Programming setup
rELY tAnk	Relay Tank - Programming tank related alarms to control relays
rELY cC	Relay Contact Closure - Programming contact closure inputs to control relays
rELY SEnS	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
rELY SItE	Relay Site - Programming site related alarms/errors to control relays
rELY ModE	Relay Mode - Status of relay operation
cC inPut	Contact Closure Input
SEnSr inP	Sensor Input
InuEntorY	Tank Inventory Log Data setup
tHEFT	Theft - Detection (Hours of operation)
ModEm	Modem Communications - Setup
dIAL out	Auto-Dial out - Setup for selected Alarms or Tank information
rEturN	Return - Exits CONFIG menu

**tAnk** Tank: Contains Tank Channel specific settings including tank geometry, alarm setpoints, tank identification, and other tank customization options.

**tAnk En** Tank Channel Enable: Requires level-gauging probe connected to the specific tank channel to be enabled.  
 Entry Type: select list  
 Range Limits: No, Yes  
 Default/Initialized value: **no**

**tAnk id** Tank ID Number: A unique two-digit numeric ID number assigned to the Tank Channel that is recorded in all reports and tank printouts.  
 Entry Type: 2-digit numeric  
 Range Limits: 01-99  
 Default/Initialized value: **01**

**Vol ModE** Volume Mode: Toggles between support for small to medium sized tanks (less than 1 million gallons/liters) and support for large tanks (1 million gallons/liters and higher).  
 Entry Type: select list  
 Range Limits: **by 1**: Supports tanks less than 1 million gallons/liters. Displayed volume rounded off to the nearest 1 gallon/liter  
**by 10**: Supports tanks 1 million gallons/liters and higher. Displayed volume rounded off to the nearest 10 gallons/liters. **Note**: All volume settings for a Tank Channel configured with a Volume Mode "by 10" must be divided by 10 from the actual value. i.e. a 2 million gallon/liter tank would have the Tank Capacity entered as 200,000 gallon/liter  
 Default/Initialized value: **by 1**

**Cr it H iSh** Product SetPoint Activation Thresholds: A Product SetPoint represents a range defined as a combination of two values: (1) the threshold is a numeric value that defines the percent volume that must be met or exceeded to be considered in alarm and (2) the direction implied by the base name of High and Low. A base name of High includes the range at and above the defined threshold while the base name of Low includes the range at and below the defined threshold. Setting the threshold to zero disables the SetPoint.  
**SP H iH**  
**SP H iSh**  
**SP Lo**  
**LoLo**  
**Cr it Lo**  
 Entry Type: 3 digit numeric as a percent of total Tank Capacity.  
 Range Limits: 0.0-99.9%  
 Default/Initialized value:

<b>Critical High:</b>	<b>98.0</b>
<b>High High:</b>	<b>95.0</b>
<b>High:</b>	<b>90.0</b>
<b>Low:</b>	<b>20.0</b>
<b>Low Low:</b>	<b>15.0</b>
<b>Critical Low:</b>	<b>12.0</b>

**Cr i t H H o r n** Product SetPoint Horn: Indicates whether the integrated horn activates for the specified Product SetPoint. The Horn will only activate if the Product SetPoint is assigned to an SP Alarm LED. See above setting regarding mapping Product SetPoints to an SP Alarm LED. Logging is unaffected by this setting.

**H i H i H o r n** Entry Type: select list

**H i g h H o r n** Range Limits: Yes, No

**L o H o r n** Default/Initialized value:

**L o L o H o r n**

**Cr i t L H o r n**

**Critical High:** no  
**High High:** YES  
**High:** YES  
**Low:** YES  
**Low Low:** no  
**Critical Low:** no

**t E n P H i H i** Temperature SetPoint Activation Thresholds: A Temperature SetPoint represents a range defined as a combination of two values: (1) the threshold is a numeric value that defines the temperature that must be met or exceeded to be considered in alarm and (2) the direction implied by the base name of High and Low. A base name of High includes the range at and above the defined threshold while the base name of Low includes the range at and below the defined threshold. Setting the threshold to zero disables the SetPoint.

**t E n P H i g h** Entry Type: numeric

**t E n P L o** Range Limits: -40.0 - 199.9°F (-40.0 - 93.0°C)

**t E n P L o L o** Default/Initialized value:

	°F	°C
<b>High High:</b>	<b>900</b>	<b>320</b>
<b>High:</b>	<b>430</b>	<b>60</b>
<b>Low:</b>	<b>400</b>	<b>40</b>
<b>Low Low:</b>	<b>250</b>	<b>-40</b>

**H H t P H o r n** Temperature SetPoint Horn: Indicates whether the integrated horn activates for the specified Temperature SetPoint. Logging is unaffected by this setting.

**H i t P H o r n** Entry Type: select list

**L o t P H o r n** Range Limits: Yes, No

**L L t P H o r n** Default/Initialized value:

**High High:** YES  
**High:** no  
**Low:** no  
**Low Low:** YES

**t A n k t y P E** Tank Type: Select between the various Tank shapes supported by the TMS. Entry Type: Select List

- Range Limits: **Flat (FLAt)**: Flat-ended horizontal cylinder, typically steel  
**Vertical (VErE)**: Tank with Vertical walls like vertical cylinders and rectangular and cubical  
**Custom 3 (CUSt 3)**: Symmetrical horizontal cylindrical tanks, typically with dished ends (fiberglass), with volume calculated using three volumes at predetermined heights provided by TMS.  
**Custom 8 (CUSt 8)**: Assymmetrical vertical tanks including trapezoid and L-shaped tanks (not common)  
**Cone (ConE)**: Vertical Cylindrical tanks with a Conical floor.

Default/Initialized value: **FLAt**

**t A n k t C A P** Tank Capacity: The maximum actual capacity of the tank being monitored. In general, if the capacity ends in zeroes, it is the marketing capacity. For example, a tank manufacturer may identify a tank as a 10,000-gallon tank but the manufacturer's calibration chart reveals the actual capacity is 9,841 gallons. **Note**: If the actual Tank Capacity is 1 million Gallons/Liters or greater, divide the actual Tank Capacity by 10 and enter here. Also change the Volume Mode to "by 10".

Entry Type: 6-digit numeric  
 Range Limits: 0 – 999,999 gallons [0 – 999,999 liters]  
 Default/Initialized value: **0**

**Manifold**

**Manifold Factor:** Primarily used to specify the number of manifolds connecting tanks of equal size using a single probe. The tanks are assumed to be level with each other. For example, two tanks would be connected by one manifold (volume calculation doubled), three tanks would be connected by two (volume calculation tripled), etc. Selecting None would identify the tank as an isolated tank.

Entry Type: select list

Range Limits: None, 1-6

Default/Initialized value: **none**


**Tank Rad**

**Tank Radius:** The inside Radius of either a Flat, Custom 3, or Cone Tank Type. See illustration at right for inside Radius shown on Flat or Custom 3 tank types. The inside Radius of a tank is calculated by dividing the inside Tank Diameter by two.


Entry Type: 4-digit numeric

Range Limits: 999.9" [9999 mm]

Default/Initialized value: **0.0 [0]**



**Tank Rise** Tank Rise: Represents the degree of tilt over the entire length of the tank. Applies to Flat and Custom 3 Tank Types. This value is entered in Level units (inches/millimeters) and represents the difference between the low and high end of the tank. See below illustration for complete details.  
 Entry Type: 2-digit numeric  
 Range Limits: 0-9.9" [0-99 millimeters]  
 Default/Initialized value: 0.0 [0]



The user sticks and records fluid level in the probe riser opening and also in another tank riser, (E.G. "Fill") and preferable at the opposite end of the tank. The fluid height difference is divided by the distance between the two risers.

**See the above figure and following Examples:**

**English**

**User Measured values:**

Fluid Level in Left Riser = 49.5"    Fluid Level in Right Riser = 47"  
 D = Distance between the risers = 250"    L = Total Tank Length = 400"

**User Calculations:**

S = Difference in fluid level between risers = 49.5" - 47" = 2.5"  
 Tank Rise (S x L ÷ D): 4" (2.5" x 400" ÷ 250")

**Metric**

**User Measured values:**

Fluid Level in Left Riser = 1250 mm    Fluid Level in Right Riser = 1200 mm  
 D = Distance between the risers = 6350 mm    L = Total Tank Length = 10160 mm

**User Calculations:**

S = Difference in fluid level between risers = 1250 mm - 1200 mm = 50 mm  
 Tank Rise (S x L ÷ D): 80 mm (50 mm x 10160 mm ÷ 6350 mm)

**Tank Ht** Tank Height: The inside height in inches/millimeters. Applies to Vertical, Custom 8, and Cone Tank Types.  
 Entry Type: 5-digit numeric  
 Range Limits: 0 - 1999.9 inches [0 - 49,999 millimeters]  
 Default/Initialized value: 0.0 [0]

**Tank Len** Tank Length: The inside length of a tilted tank in inches/millimeters. Applies to Flat and Custom 3 Tank Types. This context sensitive menu item only appears if Tank Rise is NOT zero.  
 Entry Type: 5-digit numeric  
 Range Limits: 0 - 1999.9 inches [0 - 49,999 millimeters]  
 Default/Initialized value: 0.0 [0]

**Cone Ht** Cone Height: The inside height of the conical bottom of the Cone Tank Type.  
 Entry Type: 3-digit numeric  
 Range Limits: 0 - 99.9 inches [0 - 999 millimeters]  
 Default/Initialized value: 0.0 [0]

- HEIGHT**      Height #: Applies to Custom 3 and Custom 8 Tank Types. For Custom 3, Heights 1-3 are calculated by the TMS from the Tank Radius and are NOT editable. The corresponding Volumes from the Tank Manufacturer's calibration chart should be entered in the Volume # menu item that follows. For Custom 8, Heights must be entered from lowest (1) to highest (8) with volumes entered in the corresponding Volume # menu item. Evenly spacing the heights may result in accurate readings for tank with minor symmetry problems. For more substantial differences, contact Pneumercator for guidance.  
Entry Type: 5-digit numeric  
Range Limits: 0 – 1999.9 inches [0 – 49,999 millimeters]  
Default/Initialized value: **00 [0]**
- VOLUME**      Volume #: Applies to Custom 3 and Custom 8 Tank Types. The Volumes entered must correspond to the Height # from the previous menu item.  
Entry Type: 6-digit numeric  
Range Limits: 0 – 999,999 gallons [0 – 999,999 liters]  
Default/Initialized value: **0**
- THEFT EN**      Theft Enable: Enables Theft monitoring. The Hours of Operation for the Site must be defined in the Thefts submenu within the Configuration menu. A Theft is defined as a loss of Product during a time when the facility should be Closed. Thefts meeting the Logged Minimum Volume requirement defined in the Probe submenu of the Configuration menu will be recorded in the Thefts Log.  
Entry Type: select list  
Range Limits: No, Yes  
Default/Initialized value: **no**
- UNUSABLE**      Unusable Volume: Excluded from the Total Tank Volume to create Usable Fuel Volume used in the Product Reordering (Orders) Log.  
Entry Type: 6-digit numeric  
Range Limits: 0 – 999,999 gallons [0 – 999,999 liters]  
Default/Initialized value: **0**
- UNGAUGEABLE**      Ungaugeable Level: The amount of liquid that remains in the tank after the Product float has dropped to the bottom of the probe stem. In most cases this would be a minimal amount of liquid below the siphon which is typically considered to be of no consequence. In cases where this point would be above the siphon, the TMS can provide a Low Product Information Message at the bottom of the Product Float travel.  
Entry Type: 5-digit numeric  
Range Limits: 0 – 9,999.9" [0 – 99,999 millimeters]  
Default/Initialized value: **00 [0]**
- RETURN**      Return: Press EDIT (TEST) to exit Tank submenu.  
Note: Press STEP (MODE) to return to top of Tank submenu showing **TANK EN** (Tank Enable)

3.2.3 PROBE

**CONF 19**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	<b>Probe - Programming setup</b>
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEft</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iRL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu


**PrObE**      Probe: Provides probe-specific settings that, when combined with the configuration in the Tanks submenu, allow the TMS to provide the highest degree of accuracy available.

**PrObE tYP**      Probe Type: The model number of the level gauging probe must be entered for accurate results. An incorrect selection may result in Probe Errors or inaccurate information. Found at the top of the probe on a label around the probe head (MP55x) or secured to the probe cable (MP56x).  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **NP550**  
 Item List:                      **NP550** MP550                      **NP---** Obsolete  
    **NP552** MP552                      **NP---** Obsolete                      **NP551** MP551  
    **NP561** MP561                      **NP562** MP562                      **NP563** MP563

**PrObE LEn**      Probe Length: Determines the location of the temperature sensors within the probe stem.  
 Entry Type: 5-digit numeric  
 Range Limits: Up to 1999.9 inches [Up to 49,999 millimeters]  
 Default/Initialized value: **00 [0]**

**PrOd H0**      Product Height Float Offset: Represents the adjustment to the raw probe level required to compensate for both the float depth in the liquid and mounting height of the probe. Required to provide accurate volume calculations. Calculated by taking the difference between the raw probe level and a manual stick reading of the total liquid level.  
 Entry Type: 4-digit numeric  
 Range Limits: +/- 0.0 - 299.9 inches [+/- 0 – 7,999 millimeters]  
 Default/Initialized value: **00 [0]**

**Probe Loc**      Probe Location Offset: Represents the distance from the high end of the tank to where the probe is located in the tank. This context sensitive menu item appears if the Tank Rise is NOT zero. The below example shows the offset value would be 350" [8890 mm].  
 Entry Type: 4-digit numeric  
 Range Limits: 0.0 – 599.9 inches [0 – 5,999 millimeters]  
 Default/Initialized value: **00** [0]



**Motion bAnd**      Motion Height Band: Used to identify both the beginning and ending of a liquid transaction (Delivery, Sale, Theft, Water Removal). Value entered as level units (inches/millimeters) representing the minimum change over one minute to mark the beginning of a transaction. When the Motion Height Band is NOT exceeded for three consecutive minutes, the transaction is completed provided it meets or exceeds the Logged Minimum Volume shown below.  
 Entry Type: 2-digit numeric  
 Range Limits: 0 - 0.99 inches or [0 – 99 millimeters]  
 Default/Initialized value: **020** [5]

**Log Min**      Logged Minimum Volume: Represents the smallest transaction stored in the Logs.  
 Entry Type: 3-digit numeric  
 Range Limits: 0 – 999 gallons [0 – 999 liters]  
 Default/Initialized value: **50** [200]

**rEturn**      Return: Press EDIT (TEST) to exit Probe submenu.  
 Note: Press STEP (MODE) to return to top of Probe submenu showing **Probe CF** (Probe Calibration Factor)

**3.2.4 RELAY TANK**

**CONF** *is*

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	<b>Relay Tank - Programming tank related alarms to control relays</b>
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEft</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturn</b>	Return - Exits CONFIG menu

**rELY tAnk**      Relay – Tank Triggers: Each tank alarm condition can affect up to three relay outputs. These are generally used to support select remote alarms or provide signal outputs for third party systems. The TMS1000D currently includes 4 Relay Outputs.

**Crth tr is**      Product SetPoint Triggers:  
**HHi tr is**      Product SetPoints. Generally, represent High and/or Low Product.  
**Hih tr is**      Entry Type: numeric list  
**Lo tr is**      Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**LoLo tr is**      **Note:** Each assignment separated by decimal point.  
**CrL tr is**      Default/Initialized value: **nnnnn**

**HHtP tr is**      Temperature SetPoint Triggers:  
**HtP tr is**      Temperature SetPoints. Generally, represent High and/or Low Temperature.  
**LotP tr is**      Entry Type: numeric list  
**LLtP tr is**      Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**Note:** Each assignment separated by decimal point.  
 Default/Initialized value: **nnnnn**

**rEturn**      Return: Press EDIT (TEST) to exit Relay Tank submenu.  
 Note: Press STEP (MODE) to return to top of Relay Tank submenu showing **Crth tr is** (Critical High Product SetPoint Trigger)



### 3.2.5 RELAY CONTACT CLOSURE

#### CONF 19

HEAdEr	Header - Global System Settings
tAnk	Tank - Programming setup
PrObE	Probe - Programming setup
rELy tAnk	Relay Tank - Programming tank related alarms to control relays
rELy cc	<b>Relay CC - Programming contact closure inputs to control relays</b>
rELy SEnS	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
rELy S itE	Relay Site - Programming site related alarms/errors to control relays
rELy ModE	Relay Mode - Status of relay operation
cc inPut	Contact Closure Input
SEnSr inP	Sensor Input
InuEntorY	Tank Inventory Log Data setup
tHEFt	Theft - Detection (Hours of operation)
ModEm	Modem Communications - Setup
d iAL out	Auto-Dial out - Setup for selected Alarms or Tank information
rEturN	Return - Exits CONFIG menu

**rELy cc**      Relay – Non-Hazardous Contact Closure (CC) Input Triggers: Each Non-Hazardous Contact Closure (CC) Input can affect up to three relay outputs. These are generally used to support select remote alarms or provide signal inputs from third party systems. The TMS1000D includes 2 CC Inputs and 4 Relay Outputs. The Group ID shown corresponds to the Non-Hazardous Contact Closure (CC) Input Number.

**cc tr 19**      Non-Hazardous Contact Closure (CC) Input Trigger: A CC Input can affect up to three relays in a variety of ways that depend on how the CC Input has been configured. See the Contact Closure Inputs submenu for further details.  
 Entry Type: numeric list  
 Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**Note:** Each assignment separated by decimal point.  
 Default/Initialized value: **nn.nnnn**

**rEturN**      Return: Press EDIT (TEST) to exit Relay CC submenu.  
 Note: Press STEP (MODE) to return to top of Relay CC submenu showing **cc tr 19** (CC Trigger)

**3.2.6 RELAY SENSOR**

**CONF** :

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	<b>Relay Sensor - Using Intrinsically Safe sensor inputs to control relays</b>
<b>rELY StE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iRL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturn</b>	Return - Exits CONFIG menu

**rELY SEnS**     Relay – Sensor (ISCC) Input Triggers: Each Leak/Point Level Sensor (ISCC) Input can affect up to three relay outputs. The TMS1000D includes 2 Sensor Inputs and 4 Relay Outputs. The Group ID shown corresponds to the Leak/Point Level Sensor Input Number.

**SEnS tr :**     Sensor (ISCC) Input Trigger: A Sensor Input can affect up to three relays.  
 Entry Type: numeric list  
 Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**Note:** Each assignment separated by decimal point.  
 Default/Initialized value: **nnnnn**

**rEturn**     Return: Press EDIT (TEST) to exit Relay Sensor submenu.  
 Note: Press STEP (MODE) to return to top of Relay Sensor submenu showing **SEnS tr :** (Sensor Trigger)

## 3.2.7 RELAY SITE

**CONF IG**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELy tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELy cC</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELy SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELy S tE</b>	<b>Relay Site - Programming site related alarms/errors to control relays</b>
<b>rELy ModE</b>	Relay Mode - Status of relay operation
<b>cC inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELy S tE** Relay – Site-Specific Conditions: The TMS can report select conditions are specific to the Site and not necessarily a specific probe or sensor. Each site-specific condition can affect up to three relay outputs. The TMS1000D includes 4 Relay Outputs.

**tHEFt** Theft Trigger: A loss of Product during hours that the facility should be closed is defined as a Theft. This is configured in the Configuration menu in both the Tanks and Theft submenus. A Theft can affect up to three relays.  
Entry Type: numeric list  
Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**Note:** Each assignment separated by decimal point.  
Default/Initialized value: **nnnnn**

**PowerFR iL** Power Fail Trigger: A past Power Failure of a duration of at least 1-2 minutes resulting in a Warning 21 can affect up to three relays. The Warning 21 is also recorded in the Events Log.  
Entry Type: numeric list  
Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**Note:** Each assignment separated by decimal point.  
Default/Initialized value: **nnnnn**

**SYS Error** System Error Trigger: Any System Error, including Probe and Sensor Errors, can affect up to three relays. These Errors would also be recorded in the Events Log.  
Entry Type: numeric list  
Range Limits: Each Relay: No (No Relay Assignment), 1-4  
**Note:** Each assignment separated by decimal point.  
Default/Initialized value: **nnnnn**

**rEturN** Return: Press EDIT (TEST) to exit Relay Site submenu.  
Note: Press STEP (MODE) to return to top of Relay Site submenu showing **tHEFt** (Theft)

3.2.8 RELAY MODE

**CONF**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	<b>Relay Mode - Status of relay operation</b>
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELY ModE**     Relay Mode: The behavior of each relay can be modified to support a variety of applications. These include valve and indirect pump control as well as positive shutdown. Other modifications can be made to a relays behavior to support remote horns. See below for complete details. The Group ID shown corresponds to the Relay Output Number.

**NormalLY**     Normal Contact State: A relay can be configured as Normally ON to support positive shutdown applications. In the non-alarm, non-action state, the relay output is energized resulting in the Normally Open (NO) contacts closing and Normally Closed (NC) contacts opening. When an alarm or other programmed action occurs that is assigned to the relay output, it is de-energized resulting in NO contacts opening and NC contacts closing. ALL Relay Outputs are de-energized when the TMS loses power or is powered off. Any external equipment monitoring the TMS or being controlled by the TMS would behave as though the Relay Output was in the Alarm State.  
 Entry Type: select list  
 Range Limits: Off, On  
 Default/Initialized value: **OFF**

**FP Act**     Front Panel Acknowledgment: Primarily used to support remote horns. When an alarm condition occurs that activates the relay output, the user would typically press any button on the TMS to Acknowledge the Alarm. When enabled, this setting allows that acknowledgment to also return the Relay Output to its Normal Contact State.  
 Entry Type: select list  
 Range Limits: No, Yes  
 Default/Initialized value: **no**

**dELAY**     Delay: Primarily used to support remote horns. When an alarm condition occurs that activates the relay output, the specified time delay determines when the Relay Output returns to normal, effectively acknowledging the remote horn. Choosing NONE disables this feature.  
 Entry Type: select list  
 Range Limits: **None:** Disabled  
                   **1-9 minutes:** Auto-Acknowledged after defined time delay.  
 Default/Initialized value: **none**

<b>LAtch En</b>	<p><u>Latch Enable</u>: A latching relay is useful for manipulating external valves or for providing indirect pump control for the purpose of automatically filling (supply pump) or emptying (return pump) a tank. Once the feature is enabled, the Latch Off condition must be defined in the settings that follow. The Latch On condition is defined elsewhere in the Configuration menu, most commonly in either the Relay Tank or Relay Sensor submenus.</p> <p>Entry Type: select list Range Limits: No, Yes Default/Initialized value: <b>no</b></p>
<b>Cr tH OFF</b> <b>H iH i OFF</b> <b>H iSh OFF</b> <b>Lo OFF</b> <b>LoLo OFF</b> <b>Cr tL OFF</b>	<p><u>Product SetPoint Latch Off</u>: Identifies the Product SetPoint that will return the Relay Output to its Normal Contact State. The Latch On condition would most likely be defined in the Relay Tank submenu in this instance.</p> <p>Entry Type: select list Range Limits: <b>Tank NO</b>: Specified Latch Off condition NOT selected Tank 1: Specified Latch Off condition IS selected Default/Initialized value: <b>not no</b></p>
<b>SEnSr OFF</b>	<p><u>Sensor Latch Off</u>: Specifies the Leak/Point Level Sensor used to return the Relay Output to its Normal Contact State. The Latch On condition would most likely be defined in the Relay Sensor submenu in this instance.</p> <p>Entry Type: select list Range Limits: <b>Input NO</b>: Specified Latch Off condition NOT selected Input 1: Specified Latch Off condition IS selected as Sensor 1 Input 2: Specified Latch Off condition IS selected as Sensor 2 Default/Initialized value: <b>inP no</b></p>
<b>HHtP OFF</b> <b>H i tP OFF</b> <b>Lo tP OFF</b> <b>LLtP OFF</b>	<p><u>Temperature SetPoint Latch Off</u>: Identifies the Temperature SetPoint that will return the Relay Output to its Normal Contact State. The Latch On condition would most likely be defined in the Relay Tank submenu in this instance.</p> <p>Entry Type: select list Range Limits: <b>Tank NO</b>: Specified Latch Off condition NOT selected Tank 1: Specified Latch Off condition IS selected Default/Initialized value: <b>not no</b></p>
<b>rEturn</b>	<p><u>Return</u>: Press EDIT (TEST) to exit Relay Mode submenu. Note: Press STEP (MODE) to return to top of Relay Mode submenu showing <b>NormalLY</b> (Normally)</p>

### 3.2.9 CONTACT CLOSURE INPUT

**CONF 19**

- HEAdEr** Header - Global System Settings
- tAnk** Tank - Programming setup
- PrObE** Probe - Programming setup
- rELY tAnk** Relay Tank - Programming tank related alarms to control relays
- rELY cc** Relay Contact Closure - Programming contact closure inputs to control relays
- rELY SEnS** Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
- rELY S itE** Relay Site - Programming site related alarms/errors to control relays
- rELY ModE** Relay Mode - Status of relay operation
- cc inPut** **Contact Closure Input**
- SEnSr inP** Sensor Input
- InuEntorY** Tank Inventory Log Data setup
- tHEFT** Theft - Detection (Hours of operation)
- ModEm** Modem Communications - Setup
- d iRL out** Auto-Dial out - Setup for selected Alarms or Tank information
- rEturN** Return - Exits CONFIG menu

**cc inP** Non-Hazardous Contact Closure (CC) Input: The behavior of each CC Input can be configured to support a variety of applications. These include remote Testing and Acknowledgment of remote Alarms as well as more advanced Logic AND Gate functions. See below for complete details. The Group ID shown corresponds to the CC Input Number.

**cc EnABLE** CC Input Enable: A variety of options are available for enabling a CC Input to support a number of different applications. Each choice is described below.

Entry Type: Select list (See table below)

Range Limits: **Off:** Disabled

**Relay:** Used as a control input for manipulating Relay Outputs or to support Auto In-Tank Leak Test Mode

**Gate:** AND Logic Gate created from both the CC Input and another system condition that are assigned to affect the same Relay Output.

**Alarm:** Displays an Alarm on TMS and is recorded in the Alarm Log.

**Acknowledge:** Returns assigned Relay Outputs to their Normal Contact State.

**Front Panel Ack:** An external signal, typically from an automation system, used to acknowledge the integrated horn on the front panel of the TMS.

Default/Initialized value: **OFF**

<b>OFF</b>	Off	<b>rELAY</b>	Relay	<b>gAtE</b>	Gate
<b>ALArM</b>	Alarm	<b>Rct</b>	Acknowledge	<b>FPRct</b>	Front Panel Ack

**inP nAmE** Input Name: Name of CC Input specified to identify function of CC Input. The name USER indicates a User-Defined CC Input Name. See next setting for User-Defined Name.

Entry Type: select list

Range Limits: See table below

Default/Initialized value: **USEr**

<b>USEr</b>	User-Defined	<b>gEnrtr</b>	Generator	<b>rES 1</b>	Reserve 1
<b>rES 2</b>	Reserve 2	<b>rES 3</b>	Reserve 3	<b>rES 4</b>	Reserve 4
<b>PunP</b>	Pump				

**USEr nAmE** User-Defined Input Name: A 6-character alphanumeric name entered via TMSComm. Note that this is a context sensitive setting that only appears if the CC Input Name is set for **USEr**

Entry Type: select list

Range Limits: 6-character alphanumeric. Must be entered via TMSComm.

Default/Initialized value: **inPut**

- Normal** Normal Contact State: The normal state of the signal wired to the CC Input. Commonly connected devices include the RS2 (Test/Reset buttons) and CS-10 Current Sensor which are both Normally Open.  
Entry Type: select list  
Range Limits: Open, Close  
Default/Initialized value: **CLOSE**
- Logic En** Logic Enable Group: Creates a Logic Group containing two or more CC Inputs defined by which CC Inputs are assigned to a specific letter group. ALL inputs in the group must be active to affect any Relay Outputs assigned to any of the CC Inputs in the group.  
Entry Type: select list  
Range Limits: Off, AND A – AND H  
Default/Initialized value: **OFF**
- TimeDelay** Time Delay: A Time Delay applied to a condition going active or inactive may be applied to any CC Input. For example. If a CC Input is used to monitor an external system, a Time Delay may be applied to considering the CC Input in alarm to allow time for the external system to be repowered without causing a false alarm.  
Entry Type: select list  
Range Limits: **00 SEC** : Feature disabled.  
                  **-02 SEC** : Delay reacting to condition activating for 2 seconds  
                  **-05 SEC** : Delay reacting to condition activating for 5 seconds  
                  **-10 SEC** : Delay reacting to condition activating for 10 seconds  
                  **-20 SEC** : Delay reacting to condition activating for 20 seconds  
                  **02 SEC** : Delay reacting to condition deactivating for 2 seconds  
                  **05 SEC** : Delay reacting to condition deactivating for 5 seconds  
                  **10 SEC** : Delay reacting to condition deactivating for 10 seconds  
                  **20 SEC** : Delay reacting to condition deactivating for 20 seconds  
Default/Initialized value: **00 SEC**
- Return** Return: Press EDIT (TEST) to exit CC Input submenu.  
Note: Press STEP (MODE) to return to top of CC Input submenu showing **cc ENABLE** (CC Enable)

3.2.10 SENSOR INPUT

CONF 19

- HEAdEr** Header - Global System Settings
- tAnk** Tank - Programming setup
- PrObE** Probe - Programming setup
- rELY tAnk** Relay Tank - Programming tank related alarms to control relays
- rELY cc** Relay Contact Closure - Programming contact closure inputs to control relays
- rELY SEnS** Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
- rELY StE** Relay Site - Programming site related alarms/errors to control relays
- rELY ModE** Relay Mode - Status of relay operation
- cc inPut** Contact Closure Input
- SEnSr inP** **Sensor Input**
- InuEntorY** Tank Inventory Log Data setup
- tHEft** Theft - Detection (Hours of operation)
- ModEm** Modem Communications - Setup
- d iRL out** Auto-Dial out - Setup for selected Alarms or Tank information
- rEturN** Return - Exits CONFIG menu

**SEnSr inP** Sensor (ISCC) Input: Configuration for each Sensor Input Channel to support the sensor model connected including identification and TMS behavior. The Group ID shown corresponds to the Sensor Input Number.

**SEnSr En** Sensor Enable: Enables each Sensor Input Channel to use the sensor for Alarm purposes or to exclusively use the Sensor to control of TMS functions like Relay Outputs.  
 Entry Type: Select list  
 Range Limits: **Off:** Disabled Sensor Input  
**Alarm:** Used primarily for Alarm purposes resulting in an Alarm message being displayed and an Alarm Log being generated. May also be used to control Relay Outputs  
**Relay:** Used exclusively to control Relay Outputs and will NOT generate an Alarm on the TMS.  
 Default/Initialized value: **OFF**

**tYPE** Sensor Type: The Model number of the Sensor connected to the Input.  
 Entry Type: select list  
 Range Limits: See Below Table  
 Default/Initialized value: **ES820**

<b>ES820</b>	ES820	<b>HS 100</b>	HS100	<b>LS600</b>	LS600
<b>LS6 10</b>	LS610	<b>rSU800</b>	RSU800	<b>rSU80 1</b>	RSU801 (Future Use)
<b>rSU802</b>	RSU802 (Future Use)	<b>Other</b>	Other (3 <sup>rd</sup> party float switch)	<b>ES825 1</b>	ES825-100F

**inP nAmE** Input Name: Name of Sensor Input specified to identify function of Sensor. The name USER indicates a User-Defined Sensor Name. See next setting for User-Defined Name.  
 Entry Type: select list  
 Range Limits: See Below Table  
 Default/Initialized value: **USER**

<b>USER</b>	User-Defined	<b>SuNP</b>	Sump	<b>P iP inG</b>	Piping
<b>Contn</b>	Containment	<b>dbuALL</b>	Double-Wall	<b>d iE</b>	Dike
<b>LEAK</b>	Leak	<b>rESuor</b>	Reservoir	<b>UELL</b>	Well
<b>GEnertr</b>	Generator	<b>WAtEr</b>	Water	<b>Oil</b>	Oil
<b>VAlu It</b>	Vault	<b>H i rES</b>	High Reservoir	<b>Lo rES</b>	Low Reservoir
<b>H iGh</b>	High	<b>H iH iGh</b>	High-High	<b>Lo</b>	Low
<b>LoLo</b>	Low-Low	<b>tRb inE</b>	Turbine	<b>d iSPAn</b>	Dispenser Pan



- USER NAME**      User-Defined Input Name: A 6-character alphanumeric name entered via TMSComm. Note that this is a context sensitive setting that only appears if the Sensor Input Name is set for **USER**  
Entry Type: select list  
Range Limits: 6-character alphanumeric. Must be entered via TMSComm.  
Default/Initialized value: **Input**
- FAULT En**      Fault Enable: Must be enabled for sensors with a -F suffix in the model number. The Fault-Detection feature, also referred to as Supervised Wiring, enables the TMS to monitor the field wiring for open or short circuits, preventing the TMS from determining the alarm state of the sensor.  
Entry Type: select list  
Range Limits: No, Yes  
Default/Initialized value: **no**
- NORMALLY**      Normal Contact State: The normal state of the Sensor wired to the Sensor Input.  
Entry Type: select list  
Range Limits: Close, Open  
Default/Initialized value: **CLOSE**
- return**      Return: Press EDIT (TEST) to exit Sensor Input submenu.  
Note: Press STEP (MODE) to return to top of Sensor Input submenu showing **SEnSr En** (Sensor Enable)

**3.2.11 INVENTORY**

**CONF 19**

**HEAdEr** Header - Global System Settings  
**tAnk** Tank - Programming setup  
**PrObE** Probe - Programming setup  
**rELY tAnk** Relay Tank - Programming tank related alarms to control relays  
**rELY cc** Relay Contact Closure - Programming contact closure inputs to control relays  
**rELY SEnS** Relay Sensor - Using Intrinsically Safe sensor inputs to control relays  
**rELY StE** Relay Site - Programming site related alarms/errors to control relays  
**rELY ModE** Relay Mode - Status of relay operation  
**cc inPut** Contact Closure Input  
**SEnSr inP** Sensor Input  
**InuEntorY** **Tank Inventory Log Data setup**  
**tHEft** Theft - Detection (Hours of operation)  
**ModEm** Modem Communications - Setup  
**dIAL out** Auto-Dial out - Setup for selected Alarms or Tank information  
**rEturN** Return - Exits CONFIG menu

**InuEntorY** Shift Inventory Report Schedule: Schedules up to three Inventory Snapshots per day for each of the seven days of the week. The Snapshots are recorded in the Inventory Log. The 6-record capacity of the Inventory Log allows for two days of Snapshots.

**Hour 1** Snapshot Times: The TMS will record an Inventory Snapshot for every unique time  
**Hour 2** configured in HOUR 1, HOUR 2, and HOUR 3 for the enabled Days of the Week. For if the  
**Hour 3** example, TMS had HOUR 1 and HOUR 2 set for 00'00 (Midnight) and HOUR 3 set for  
 12'00 (Noon), the TMS would record TWO Inventory Snapshots for each enabled Day of  
 the Week, one at midnight and one at noon.  
 Entry Type: 4 digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59. (24-hour clock format)  
 Default/Initialized value: **0000**  
 Example 12'00 = 12 Noon                      23'59 = 11:59 PM                      00'00 = Midnight

**Sun EnAbL** Days of the Week: The TMS will record an Inventory Snapshot for every unique time  
**Mon EnAbL** configured in HOUR 1, HOUR 2, and HOUR 3 for the enabled Days of the Week. Enable  
**tue EnAbL** each Day of the Week desired by choosing Yes.  
**UEd EnAbL** Entry Type: select list  
**thu EnAbL** Range Limits: No, Yes  
**Fr i EnAbL** Default/Initialized value: **no**  
**SAt EnAbL**

**rEturN** Return: Press EDIT (TEST) to exit Inventory submenu.  
 Note: Press STEP (MODE) to return to top of Inventory submenu showing **Hour 1**  
 (Hour 1)

## 3.2.12 THEFT

## CONF 19

<b>HEAdEr</b>	Header - Global System Settings
<b>tRnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tRnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY StE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InventorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	<b>Theft - Detection (Hours of operation)</b>
<b>ModEm</b>	Modem Communications - Setup
<b>dIAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**tHEFt**      Theft – Detection (Hours of operation): Defines the Site Hours of Operation. Any loss of Product during the hours the facility is Closed is defined as a Theft. Individual Tank Channels may have Theft monitoring enabled with the Theft enable setting in the Tanks submenu within the Configuration menu.

**W-F OPEN**      Weekdays (Monday – Friday) Hours of Operation: Define the hours the facility opens and  
**W-F CLOSE**      closes during the week.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59. (24-hour clock format)  
 Default/Initialized value: **0000**  
 Example 12'00 = 12 Noon                      23'59 = 11:59 PM                      00'00 = Midnight

**SAt OPEN**      Saturday Hours of Operation: Define the hours the facility opens and closes on Saturday.  
**SAt CLOSE**      Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59. (24-hour clock format)  
 Default/Initialized value: **0000**  
 Example 12'00 = 12 Noon                      23'59 = 11:59 PM                      00'00 = Midnight  
 Note: Set the Open and Close times to match if the facility is closed on Saturday.

**SUn OPEN**      Sunday Hours of Operation: Define the hours the facility opens and closes on Sunday.  
**SUn CLOSE**      Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59. (24-hour clock format)  
 Default/Initialized value: **0000**  
 Example 12'00 = 12 Noon                      23'59 = 11:59 PM                      00'00 = Midnight  
 Note: Set the Open and Close times to match if the facility is closed on Sunday.

**rEturN**      Return: Press EDIT (TEST) to exit Theft submenu.  
 Note: Press STEP (MODE) to return to top of Theft submenu showing **W-F OPEN**  
 (Monday-Friday Open)

3.2.13 MODEM

**CONF**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEft</b>	Theft - Detection (Hours of operation)
<b>ModEn</b>	<b>Modem Communications - Setup</b>
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**ModEn**      Modem: Allows the user to enable and configure the secure internal modem system within the TMS locking enclosure to assure a positive telephone link; free of tampering.

**ModEn**      Modem Selection: Select which type of modem is installed in the TMS.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **nonE**  
 Item List:      **nonE** = No modem installed                      **intErnAL** = Internal modem  
                      ----- = Not available                                      **Port Mod** = External serial port modem

**baud rAtE**      Baud Rate: Defines the maximum baud rate allowed for the installed TMS modem.  
 Entry Type: Select list  
 Range Limits: 1.2K, 2.4K, 4.8K, 9.6K, 14.4K (K = 1,000. i.e 9.6K =9600)  
 Default/Initialized value: **24**

**d iAL tYPE**      Dial Type: Select TONE (Touch-Tone) for phone lines that support pushbutton phones or PULSE for phone lines that only support rotary dial phones  
 Entry Type: Select list  
 Range Limits: Tone, Pulse  
 Default/Initialized value: **tonE**

**PAUSE**      Pause Length: Supports the Dial-Out function. Defines the number of seconds a single Pause or comma represents in the dial-out string.  
 Entry Type: 1-digit numeric, seconds  
 Range Limits: 1-9 Seconds  
 Default/Initialized value: **1 SEc**

**tEL L inE**      Telephone Line Mode: Supports the Dial-Out function. Indicates whether the phone line is Dedicated to the TMS or being Shared with other devices. If the phone line is Shared, a dial tone must be detected prior to any Dial Out attempt.  
 Entry Type: Select list  
 Range Limits: Dedicated, Shared  
 Default/Initialized value: **dEd icALEd**

**rEturN**      Return: Press EDIT (TEST) to exit Modem submenu.  
 Note: Press STEP (MODE) to return to top of Modem submenu showing **ModEn** (Modem)

3.2.14 DIAL-OUT

**CONF 19**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iRL out</b>	<b>Auto-Dial out - Setup for selected Alarms or Tank information</b>
<b>rEturN</b>	Return - Exits CONFIG menu

**d iRL out**      Auto-Dial out – Setup for selected Alarms or Tank information: The TMS can initiate contact using an internal modem or faxmodem to provide notifications of Alarm conditions and scheduled inventory updates. Up to five sets of conditions may be defined, each with a different phone number and destination device. The Group ID indicates the set number. The TMS will make a total of five dialout attempts per condition. The dialout sequence may be aborted by clearing the Dialout memory in the Init Data submenu.

**tEL LOCAL**      Telephone Number: Up to 21 digits available for defining the dial-out sequence including the telephone number and any required prefix or suffix details. Complete 21-digit value formed as Tel Area 2 + Tel Area + Tel Local, each with a 7-digit maximum.  
**tEL Ar-ER**  
**tEL Ar-ER2**  
 Entry Type: 7-digit numeric each  
 Range Limits: 0-9, P (Pause), \_ (Blank)  
 Default/Initialized value: -----

**LiNE tYPE**      Line Type: The type of receiving device connected to the telephone line that the TMS will be communicating with.  
 Entry Type: Select list  
 Range Limits: **dAtA** (Data): Transfer data to computer running Autopolling  
                   **---**: Not Available  
                   **tTy** (TTY): TeleType text only transmission.  
                   **nPAGEr** (NPager): Numeric Pager  
 Default/Initialized value: **dAtA**

Dialout Conditions: The TMS will attempt to contact the Receiving Device defined in Line Type above for any of the conditions selected below:

<b>Cr tHd iRL</b>	Critical High Product Alarm
<b>H iH i d iRL</b>	High High Product Alarm
<b>H iGh d iRL</b>	High Product Alarm
<b>Lo d iRL</b>	Low Product Alarm
<b>LoLo d iRL</b>	Low Low Product Alarm
<b>Cr tLd iRL</b>	Critical Low Product Alarm
<b>tHFE d iRL</b>	Theft Alarm
<b>cc d iRL</b>	Non-Hazardous Contact Closure (CC) Input Alarm
<b>SEnS d iRL</b>	Sensor (ISCC) Alarm
<b>Err d iRL</b>	System Error
	Entry Type: Select List
	Range Limits: No, Yes
	Default/Initialized value: <b>no</b>

**inu d RL**      Inventory Dialout: Enables the TMS to initiate a dialout contact at the time scheduled below when there are new Inventory Logs created since the last Inventory Dialout.  
Entry Type: Select List  
Range Limits: No, Yes  
Default/Initialized value: **no**

**inu Hour**      Inventory Dialout Time: Defines the time at which the Scheduled Inventory Dialout occurs. This context sensitive menu is only visible if the Inventory Dialout is set to YES.  
Range Limits: 00'00 – 23'59. (24-hour clock format)  
Default/Initialized value: **0000**  
Example 12'00 = 12 Noon              23'59 = 11:59 PM              00'00 = Midnight

**rEturn**      Return: Press EDIT (TEST) to exit Dial Out submenu.  
Note: Press STEP (MODE) to return to top of Dial Out submenu showing **TEL LOCAL** (Tel Local)

**3.3 CLOCK****ACCESS****Lo9****Conf .9****[ loc†****in tk dRtR****rEturn****[ loc†**

**System Clock:** The system Clock includes the Date, Time, and Day of the Week. This information is used to support the Logging of system information and the execution of In-Tank Leak Tests. It is also used to recognize transactions, liquid additions and removals from the tank. See Configuration menu, Header submenu to enable automatic time adjustments to follow 2007 U.S. Daylight Savings Time rules.

**nn-dd-yy****Date (Month-Day-Year):**

Entry Type: Valid numeric dates.

Range Limits: 01-12, 01-31, 00-99

**HHmmSS****Time (Hours' Minutes' Seconds):** User enters current time of the day in Hours, Minutes, and Seconds of the day into the TMS in 24-hour scale.

Entry Type: Valid numeric time in 24-hour format

Range Limits: 1-23, 1-59, 1-59.

Examples: 12'00 = 12 Noon      23'59 = 11:59 PM      00'00 = Midnight

**dRy****Day of the Week:** User enters current day of the week.

TMS listed options include:

Entry Type: select list

Range Limits: Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday

**rEturn****Return:** Press EDIT (TEST) to exit Clock menu.Note: Press STEP (MODE) to return to top of Clock submenu showing **nn-dd-yy** (Date)

### 3.4 INIT DATA

**ACCESS**      **Lo9**  
                   **CONF :9**  
                   **[ locT**  
                   **in it dAtA**  
                   **rEturn**

**in it dAtA** Initialize Data: Initialize or erase select sections of memory. This is typically only done to restore a TMS to its factory initialized state or to eliminate memory corruption from Logs. This process is NOT reversible.

**in it**            Initialize: A description of each section that can be initialized is provided below:  
 Entry Type: select list  
 Range Limits: **nonE**: Do not initialize any Data.  
                   **InuEntorY**: Inventory Log  
                   **dEL uErY**: Delivery Log  
                   **SALES**: Bulk Sales Log  
                   **tHEFTS**: Thefts Log  
                   **OrdErS**: Product Reordering Report  
                   **ALARnS**: Alarms Log  
                   **EuEntS**: Events Log  
                   **d iAL out**: Clears the Dial-Out queue. Once the queue is cleared, no further Dial-Out attempts will be made until a new condition occurs.  
                   **All Lo9S**: All Logs  
                   **CONF :9**: Configuration. All system programming is returned to factory defaults.  
                   **ALL**: All: Initialize All Logs and System Configuration.  
                   **rEturn**: Return: Exits Initialize Data menu

**rEturn**            Return: Press EDIT (TEST) to exit Init Data menu.  
 Note: Press STEP (MODE) to return to top of Init Data submenu showing **in it** (Initialize)



## APPENDIX A

## TMS CONSOLE ALARM &amp; EVENT CONDITIONS TABLES

**Alarm Conditions:**

The following alarm conditions are recorded in the **Alarm Log**. Alarm conditions are also user programmable to auto-dial out upon alarm.

**Leak and Setpoint** alarms will produce both audible and visual LED annunciators until acknowledged via Front panel or Edit enable buttons. Visual LED conditions will continue until the specific leak or setpoint conditions are corrected.

**Theft alarms** will produce an audible annunciator and appear on the TMS display showing a theft message condition across the display. Theft alarms can only be acknowledged via the **Edit enable** button. The displayed message will continue until the condition is corrected.

**CC and SENSOR alarms** will produce an audible annunciator and appear on the TMS display showing a CC or SENSOR alarm message across the display. The audible annunciator can be acknowledged via Front panel or Edit enable buttons. The CC or SENSOR displayed message will continue until the condition is corrected.

Alarm Description			
LED	Display Message		Description
	Line 1	Line 2	
	SP1		
SP2	N/A	N/A	
SP3			
Temp	N/A	N/A	Product Temperature SetPoint Alarm: Factory defaults are as follows: High High: 90°F/32°C High: 43°F/6°C Low: 40°F/4°C Low Low: 25°F/-4°C
N/A	Theft (Tank ID)	(Tank Name)	Theft of product from the tank
N/A	CC (Input #)	(CC Input Name)	Device wired to CC Input is in alarm
N/A	Sensr (Input #)	(Sensor Input Name)	Point level (High, Low, etc.) sensor is in alarm
Leak	Sensr (Input #)	(Sensor Input Name)	Non-discriminating leak sensor is in alarm
Leak	Sensr o(Input #) Sensr w(Input #)	(Sensor Input Name)	Discriminating leak sensor (ES825-400FL) is in alarm

Note: ISCC or Intrinsically Safe Contact Closure is synonymous with Leak/Pt. Level Sensor

**Error Conditions:**

All Error conditions are recorded in the Event Log. Error conditions are also user programmable to auto-dial out upon alarm. Errors will produce an audible alarm and appear on the TMS display showing the specific error condition and code number. Errors conditions can only be silenced by acknowledging the Front panel buttons. The displayed error message will continue until the condition is corrected.

Event Description for Errors			
Error	Display Message		Description
	Line 1	Line 2	

**Configuration Memory (CM1) Chip**

5	EEPROM	Err05	Checksum Error
---	--------	-------	----------------

**Identification:**  
900699-1 Main Board: U11 socket

**Troubleshooting:**  
Reseat CM1 Chip.  
Replace CM1 Chip.  
Repair/Replace Main Board, P/N 900699-1

**Magnetostrictive Probe**

10	Probe Err	(Tank ID) Err10	Probe Level Error: Invalid Fluid Level being received from probe
11	ProbeTime	(Tank ID) Err11	Probe Timeout Error: No signal being detected from probe
13	ProbeTemp	(Tank ID) Err13	Probe Temperature Error: Invalid Fluid Temperature being received from probe.

**Troubleshooting:**  
Power off TMS and check/repair all cable connections/splices.  
Confirm and correct TMS configuration for proper probe model number.  
Connect probe directly to TMS, if possible, to eliminate field wiring problem.  
Use test probe to eliminate probe problem.

**Leak/Point Level Sensor**

20	SensShort	(Sensor #) Err20	Sensor Fault – Short Circuit: Wiring fault with all sensors
21	Sens Open	(Sensor #) Err21	Sensor Fault – Open Circuit: Wiring fault with all sensors

**Troubleshooting:**  
Power off TMS and check/repair all cable connections/splices.  
Confirm and correct TMS configuration for proper sensor model number and supporting configuration settings.  
Connect sensor directly to TMS, if possible, to eliminate field wiring problem.  
Use alternate sensor to eliminate sensor problem.  
Use alternate Main Board to eliminate Main Board.

Note: ISCC or Intrinsically Safe Contact Closure is synonymous with Leak/Pt. Level Sensor

**Warning Conditions:**

With the exception for a Power Failure, Warning 21 (*Pwr Fail Warn 21*), warning conditions are not logged in the **Event Log**. Warnings will produce an audible alarm and appear on the TMS display showing the specific warning condition and code number. Warning conditions may be user acknowledged via Front panel buttons.

Event Description for Warnings			
Warning	Display Message		Description
	Line 1	Line 2	

Modem			
1	Mdm Init	Warn 1	Initialization Error
2	Mdm Cmd	Warn 2	Command Error
3	Mdm Time	Warn 3	Response Timeout Error
4	Mdm DCD	Warn 4	No Carrier
5	Mdm Comm	Warn 5	Communications Error

**Troubleshooting:**

Use alternate Modem Card to eliminate Modem.

6	Dialtone	Warn 6	No Dial Tone
---	----------	--------	--------------

**Troubleshooting:**

Confirm phone line complies with POTS standard.

Test phone line using known good telephone.

Use alternate Modem Card to eliminate Modem.

Configuration Checksum Error			
7	Tank Sum	Warn 7	Tank
7	Cfg Tank	Warn 7	Tank
8	Cfg Probe	Warn 8	Probe
9	Header	Warn 9	Header
10	Rly Tank	Warn10	Relay Tank
11	Rly CC	Warn11	Relay CC
12	Rly Sensr	Warn12	Relay Sensor
13	Rly Site	Warn13	Relay Site
14	Rly Mode	Warn14	Relay Mode
15	CC Inp	Warn15	CC Input
16	Sensr Inp	Warn16	Sensor Input
17	Inventory	Warn17	Inventory
18	Cfg Theft	Warn18	Theft
19	Cfg Modem	Warn19	Modem
20	Dialout	Warn20	Dial Out

**Troubleshooting:**

Power off TMS for two seconds to determine if problem is persistent.

Review configuration in affected area and correct any invalid data.

Restore configuration from a known good source.

Repair/Replace Main Board, P/N 900699-1.

Miscellaneous			
21	Pwr Fail	Warn21	Power Fail Detected

**Note:**

Reported after a 1-2 minute loss of power when the power has been restored.

28	FrE Comm	Warn28	Front End Communication
----	----------	--------	-------------------------

**Corrective Action:**

Indicates a communications failure on the Main Board. Power off the TMS1000D, wait at least two seconds, and power on the TMS1000D. If the Warning persists, the Main Board, P/N 900699-1, will need to be repaired or replaced.

Note: ISCC or Intrinsically Safe Contact Closure is synonymous with Leak/Pt. Level Sensor

**Information Messages:**

Information messages convey statuses generally considered to be advisory. These types of messages appear only on the TMS display until acknowledged via Front panel buttons. They do not generate audible/visual alarms, and are not captured in any of the system logs.

Event Description for Information Messages			
Info #	Display Message		Description
	Line 1	Line 2	

2	Low Prod	(Tank ID) Info02	Ungaugeable Level
---	----------	------------------	-------------------

**Note:**

TMS informs user that the product float for the indicated tank has reached a float collar stop or its minimum gaugeable level some distance above the actual tank bottom. This condition is usually associated with probes requiring "Special Tank TOP mounting". The Ungaugeable Level may be configured for all enabled tanks in the **Config Tank Menu**.

**APPENDIX B: MAINTENANCE**

This maintenance documentation presumes that the system to be tested has been installed in accordance with all current documentation for the system and has been started up by a factory certified technician. If you feel that this service has not been performed, adequately or otherwise, please contact your local authorized Pneumercator service provider to make the necessary arrangements.

The TMS1000D will be able to detect many conditions, including memory failure within the system, probe communication issues, and sensor wiring faults (when equipped with a Pneumercator fault detecting sensor). Reviewing and addressing any Alarm or Event conditions displayed on the TMS would be the best place to start for determining the proper functioning of the system. Inspection of all cabling for cracking or swelling and evaluating the condition of the splices will help to maintain a properly working system.

Before connecting or disconnecting ANY cables, power off the system. Once the cabling changes are complete, the system can be powered on.

While annual inspection is considered to be a good general practice, it may be required by regulation or application to perform inspections more frequently.

The following table includes a model specific list of additional points of inspection.

Model(s)	Check points
TMS	<ol style="list-style-type: none"> <li>1. Press the TEST button to verify all integrated lights and horn are functioning</li> <li>2. Take a stick reading of the tank and confirm that the TMS Level Reading matches the stick reading. If there is a discrepancy, perform the float height offset procedure as outlined in the Quick Startup Guide.</li> </ol>
Rigid Probes (MP55xS)	Remove the probe to verify there is no damage to the floats and no residue buildup on the floats or probe shaft. Clean as necessary.
ES825-300FL (non-discriminating)	Remove and inspect the sensor for physical damage. Test the sensor by placing in a nonreflective water-filled container shielded from ambient light. Verify the alarm received on the system display is as expected. Clean sensor to remove any contaminants.
Float switch sensors: Includes: LS600, LS600LD, LS610, RSU800	Remove and inspect the sensor for physical damage or debris that may obstruct the movement of the float. Test the sensor by manipulating the float. Verify the alarm received on the system display is as expected. Clean sensor to remove any contaminants, as necessary.
Remote Alarms: Includes all RA and select LC1000 systems	Press the Test button associated with the remote alarm. It is also recommended to simulate an alarm on the controlling system to verify the operation of the remote alarm.

**APPENDIX C****TMS Main Board Dip Switch Settings**

The TMS1000D is equipped with a Main System Board that is supplied with DIP switches that have been factory set. Switches are housed in a small rectangular Red enclosure and are numbered 1-4.

**Note:** As always, any mechanical or electrical modifications to TMS system (including switch settings), probe, sensor, or other accessories requires the console to be powered-down.

**DIP Switch Function/Condition:**

**SW1:** Edit Enable – With the rocker arm in the OPEN position, this switch activates the **Edit Enable** feature. This allows the user to make any necessary programming changes via the front panel buttons.

**SW2:** Unused – Factory set at Closed.

**SW3:** Motion Band Symbol – With the rocker arm in the OPEN position, this switch activates the System **Motion Band Symbol**, producing a lower case horizontal line to the right of the Tank ID #. This visual display represents movement of product in the tank for either Deliveries, Sales, or Thefts. Any of these conditions will be logged as a function of the Motion Band sensitivity setting, which is user programmed in the CONFIG PROBE menu. This symbol will disappear from the display within 3 minutes after the tank contents has settled and stopped moving. The motion band symbol will also be present on system power up. The audible annunciator will not be activated during this condition.

**SW4:** Communications Security – With the rocker arm in the OPEN position, this switch activates the TMS **Communication Security** feature. This feature is used when a pass code is desired to prevent unauthorized access when communicating with the TMS. This switch works in conjunction with the Security setting found in the Header menu.



# PNEUMERCATOR TMS SERIES

## LIMITED WARRANTY

### TMS Series

**Pneumercator**, here and after referred to as **PCO**, warrants its **TMS Series** family of products to be free of defects in material and workmanship for a period of **Twelve (12) months** from date of installation or **Fifteen (15) months** from date of invoice, whichever comes first.

During the warranty period on the **TMS Series, PCO**, or factory third party independent representatives will repair or replace the product at the location where it is installed at no additional cost to the customer.

Packages must be inspected upon receipt for damage, missing parts, and/or manuals. **PCO** must be contacted by telephone immediately with a description of damaged or missing parts so replacements can be sent. Written details must be sent within **thirty (30) days**.

Pneumercator will not be responsible for shipping charges incurred by the customer.

Warranty repair coverage invoices will be paid if **all** the following conditions are met:

- PCO has acknowledged and authorized warranty work to be done by issuing a *Warranty Repair Number*.
- Start-up Service technician has been trained by PCO
- Warranty start-up form has been submitted to PCO
- Technician fills out and submits a PCO "Service Report"
- Parts (if any) used are returned to PCO with a proper WRGA (*Warranty Return Goods Authorization*)
- Returned parts are found to be defective.

Repair time will be paid according to PCO document "Standard Warranty Labor Charge Schedule"

If the Warranty Registration/Start up Check List has been completed and returned on file with the factory and the product is installed in accordance with the specific PCO Installation Product Manual, PCO will activate and meet warranty criteria as described above. Warranty criteria shall be voided if any product has been subjected to misuse, negligence, damage from acts of nature (lightning, wind, rain, etc.) or is in violation of the products design intent, disregard to warnings, instructions, modified or repaired by unauthorized personnel or improperly installed. Given that the third party independent contractor has installed the equipment in accordance with the specific product instruction manual, and followed all precautions, PCO will fulfill the terms stated in our warranty obligation.

Under no circumstances does the warranty provide a remedy in excess of the equipment. No other expressed or implied warranty is given by PCO. PCO shall not be liable for consequential damages or any expenses incurred by the user.

Distributed by:

 **PNEUMERCATOR**  
*Liquid Level Control Systems*

1785 Expressway Drive North, Hauppauge, NY 11788  
(631) 293-8450 Fax (631) 293-8533