


# INSTRUCTION DRAWING - TMS2000/3000 RS-232 COMMUNICATIONS TO FUELMASTER

## WIRING FOR RUNS OF 25' OR LESS (SEE PAGE 2 FOR RUNS OVER 25')

PARTS LIST					
PART	PNEUMERCATOR P/N	*MOUSER P/N	*AMP P/N	*BELDEN P/N	PHOENIX P/N
CONNECTOR PLUG	254022-1	-	-	-	1769049
TEL. CABLE	122521-4S25	172-UL4010	-	-	-
PLUG (1-REQ'D)	142057-1	154-UL6234	5-641337-4	-	-

\* OR EQUIVALENT



# INSTRUCTION DRAWING - TMS2000/3000 RS-232 COMMUNICATIONS TO FUELMASTER

**WIRING FOR RUNS FROM 25' TO 500' MAX** (SEE PAGE 1 FOR RUNS LESS THAN 25')

PARTS LIST					
PART	PNEUMERCATOR P/N	*MOUSER P/N	*AMP P/N	*BELDEN P/N	PHOENIX P/N
CONNECTOR PLUG	254022-1	-	-	-	1769049
COMP. CABLE	122536-3	-	-	9927	
JACK PLATE	142058-1	154-3007	-	-	
TEL. CABLE	122521-4S25	172-UL4010	-	-	
PLUG (2-REQ'D)	142057-1	154-UL6234	5-641337-4	-	

\* OR EQUIVALENT

